


Specifications

Model Name: IdeaPad U1 Machine Type: 20083/4398

Slate	
Form Factor	
Size	262.5mm x 187.5mm x 12.9mm
Weight	760 g (WiFi/Leather housing/With battery) 770 g (WiFi/Painted housing/With battery)
System	
Platform	Qualcomm Snapdragon 8650A Platform
Memory	PC DDR2 1GB
LCD	10.1" HD LED (1280 x 800 Widescreen view)
Integrated Camera	2.0 mega pixel camera
Battery	27 Wh, 2-cell Li-polymer battery
Operating System	
Lenovo OS (Android 2.2) supported	
Ports	
SIM card slot (Optional) Tablet-Dock connector 3.5 mm earphone x 1	
Communication	
Wifi Bluetooth	
Peripherals	
Bluetooth headset and microphone	
Others	
Multi-touch (4-finger touch) supported Built-in microphone Stereophonic loudspeakers x 2 Gravity sensor (3-axis compass supported)	

Base	
Form Factor	
Size	270mm x 210mm x 16.6-33.2mm
Weight	1.01 kg With battery
System	
Platform	Intel Calpella CULV Platform
Memory	SODIMM DDR3 1066MHz 2GB
Battery	—
Keyboard	Full-size keypad
HDD	2.5", 7 mm SATA
AC Adapter	20V, 65W
Operating System	
Windows 7	
Ports	
USB 2.0 port X 1 Headphone jack X 1 HDMI X 1 AC power adapter jack Tablet-Dock connector	
Communication	
10/1000M Ethernet	
Peripherals	
Bluetooth headset and microphone	

Unpack (and check the components)



- Some models may contain items that are not listed.
- If any item is missing or damaged, please contact your retailer.

* Lenovo is trademarks or registered trademarks of Lenovo in the United States, other countries, or both.
* Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

This [Company Product] contains Adobe® Reader® Mobile software under license from Adobe Systems Incorporated, Copyright © 1995-2009 Adobe Systems Incorporated. All rights reserved. Adobe and Reader are trademarks of Adobe Systems Incorporated.

Other company, product or service names may be trademarks or service marks of others.



P/N:148002367
Printed in China

lenovo

IdeaPad U1 (Y1021)

Quick Start Guide v1.0




Please read the safety precautions and important notes in the supplied manual before you use your computer.


ideapad

Initial Setup Procedure

1 Charge the battery



2 Turn on the pad



3 Complete system installation



4 Remove the Pad



5 Install the Pad



Port Assignment and Button Layout



OFN Gesture Definition:

Landscape mode:



Upward: Menu
Click: Home screen
Long press: Applications management
Downward: Back

Portrait mode:



Leftward: Back Click: Home screen Rightward: Menu
Long press: Applications management

Applications Overview

	Web browser	Browses websites. The web browser in this unit can access the Internet via the WIFI network for business and personal use.
	Email box	Receives/Sends and views mails by linking directly to your enterprise mailbox, Unicom mobile phone mailbox, 163 mailbox, Sina mailbox, Sohu mailbox, Netease 188 mailbox, Netease VIP mailbox, 126 mailbox, yeah.net, etc.
	Image viewer	Browses and edits images. In an image full-screen page, it supports slideshow functions and such operations as Share, Set as, and Details.
	Video player	Plays all videos stored in the unit.
	E-book	Reads e-books in formats like Epub, html, txt and PDF, and sorts these e-books accordingly.
	Backup and Recovery	Lets you backup the data in your unit clearly, easily and quickly. You can backup your schedules, Address List and settings.
	Calendar	Creates new events, toggles the day view, the week view, the month view and the daily form, and enables the event reminder function.
	Address List	Allows you to add or delete contacts and edit or delete particulars of a contact.
	LeZone	LeZone is a synchronization tool between the LePad and your PC. It synchronizes the photos, tracks, videos, e-books and office documents in your computer by category to your LePad media library and manages the media library. In addition, it also offers a file browser for you to access files outside the LePad media library.


Gravity sensor and multi-touch

Use the IdeaPad U1 in the landscape or portrait mode

You can rotate the IdeaPad U1 screen to your preferred direction.



The screen rotation lock can make the IdeaPad U1 screen stay in the landscape or portrait mode. You can lock the IdeaPad U1 screen in the current direction by sliding the screen rotation lock downward. To unlock the screen direction, just slide the screen rotation lock upward.



Use the multi-touch function

The multi-touch function enables you to perform various operations on the screen.

Open an application



Open an application: Tap the icon of this application on the screen. By clicking the home screen button, you can return to the home screen. Long press the key to restart this application.

Scroll



Scroll the screen by dragging up or down on the content.

Zoom in or out



You can zoom in or out a photo, map or webpage while viewing it. To do so, just move your two fingers apart or together.

Precautions and Tips for IdeaPad U1

- Never drop, strike, scratch, twist, knock, vibrate or push the IdeaPad U1 or place any heavy objects on it.
- Gently touch the pad.
- Keep the pad away from any magnetic substances, mobile phones in conversation, electrical appliances or speakers.
- Avoid exposing the pad to extreme temperatures (lower than 5°C or higher than 35°C).
- Do not place the pad in a damp environment.
- Do not use corrosive detergents or solvents to clean your IdeaPad U1. Just wipe the pad screen with a damp, soft, lint-free cloth to clear fingerprints off it.
- Be sure to unlock the buckle on the dock before plugging the pad and lock the buckle after unplugging the pad. Be careful not to damage the slot of the dock and the edges of the upper cover while plugging/unplugging the pad.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission (FCC) Radiation Exposure Statement

This EUT is compliance with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C.