**Open View of EUT – 1** 




**Open View of EUT – 2** 







**Open View of EUT – 4** 




## **Open View of EUT – 5**




**Open View of EUT – 6** 




## Internal View of EUT – 1




Internal View of EUT – 2



Internal View of EUT – 3



Internal View of EUT – 4



## BT Antenna Location