

Bluetooth Slide Keyboard

SKB-3500

Version 1.0 2011/09

ID NO:

About This Manual

This manual is designed to assist you in installing and using the Bluetooth Keyboard Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice.

Edition

1st Edition,

Copyright

© Copyright 2011

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

FEDERAL COMMUNICATIONS COMMISSION STATEMENT

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/ TV technician for help.

Operation is subject to the following two conditions:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.










Device pairing






1. Turn on the keyboard power and press the “CONN” button. (Please make sure the blue LED is flashing)
2. You can see the device” Bluetooth Keyboard” on your display and choose “Connect”.
3. Input the pin code on your display and press “Enter”.
4. Start to use your Bluetooth keyboard.



Note: 1. After 30 minutes non-operation, the keyboard will go to sleep mode. Please press any key to wake up.

2. Power ON/OFF also need to press any key to reconnect.

Hot key function:

Function Name		Function Description
	Language	Change the input language.
	Menu	Back to main screen.
	Search	Search file.
	Photo	Launch photo program.
	Screenshot	Screenshot current window.
	Keyboard	Call the virtual keyboard.
	Cut	Cuts the selected item.
	Copy	Copies the selected item.
	Paste	Pastes the previously cut or copied item.

	Pre-track	Switches to the previous media track. Press once for each preceding media track.
	Play/Pause	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.
	Next track	Switches to the next media track. Press once for each subsequent media track.
	Mute	Mutes the computer's sound volume. Press it again to turn the system volume back on.
	V-	Decreases the computer's sound volume. Hold down to decrease volume more quickly.

	V+	Increases the computer's sound volume. Hold down to increase volume more quickly.
	Screen Lock	Press once to lock/unlock the screen.

The “Control”, “Option” and “⌘” are no function under US layout.

Rechargeable Battery:

Please charge the battery before you use until the red LED turn off.

Power on: Press any key to connect and wait the LED flashing off before you use.

Hall Sensor:

Slide on: Connect with the device automatically.

Slide off: Go to the sleep mode to save the battery power.