

NUMBER OF CHANNELS
17 SHOW

ATTEN 20DB


MKR 8.00DBM

RL 10.0DBM

10DB/

906.013MHZ

MKR
906.013 MHZ
8.00 DBM



START 902.000MHZ

STOP 910.000MHZ

*RBW 100KHZ


VBW 100KHZ

SWP 50.0ms

ATTEN 20dB
RL 10.0dBm

10dB/

NUMBER OF CHANNELS
21 SHOWN
MKR 1.17dBm
915.02MHz



START 910.00MHz STOP 920.00MHz
*RBW 100kHz VBW 100kHz SWP 50.0ms

NUMBER OF CHANNELS
12 CH SHOWN


ATTEN 20DB

MKR 5.17DBM

RL 10.0DBM

10DB/

924.013MHZ



START 920.000MHZ

STOP 928.000MHZ

*RBW 30KHZ

VBW 30KHZ

SWP 50.0ms