

Attaching your Ricochet Modem to a Laptop Computer

Your Ricochet modem can be attached to your laptop computer for convenience. The modem accessory kit includes adhesive-backed Velcro strips for this purpose. Use these instructions to attach your modem to your laptop correctly.



Laptop computer with a Ricochet modem attached.

1. Remove the plastic backing from the **hook** side Velcro strips to expose the adhesive.
2. Affix these strips to rear of the modem, taking care not to obstruct any openings or labels. Press the strips to the modem firmly to ensure contact.
3. Attach the **loop** side Velcro strips to the **hook** strips. Remove the plastic backing from the **loop** side Velcro to expose the adhesive.
4. Align the top edge of the modem with the top edge of the computer screen for unrestricted antenna travel. Press the modem and exposed adhesive strips onto the back of your laptop computer screen.
5. Go to the Hardware Installation section of your QuickStart guide for further installation instructions.

The modem can be removed and re-attached easily, using the velcro strips.

Your modem can be used without attaching it to your computer:



Laptop computer with a Ricochet modem unattached.

1. Place the modem alongside the computer.
2. Make sure the antenna has an unrestricted range of movement.
3. Go to the Hardware Installation section of your QuickStart guide for further installation instructions.