


|   |   |  |   |
|---|---|--|---|
| <div data-bbox="432 1712 757 1776"><b>ViewSonic</b></div> <div data-bbox="446 1813 639 1844">Model Name :</div> <div data-bbox="446 1869 842 1920"><i>ViewPad E72 (Black)</i></div> | <div data-bbox="970 1793 1150 1862">Silkscreen<br/>Description:</div> | <div data-bbox="1199 1694 1456 1725">Graphic: Scale: 1:1</div> <div data-bbox="1227 1762 1510 1798"><i>ViewPad E72 Back</i></div> <div data-bbox="1238 1816 1464 1866"><div>Pantone: 427C (Gery)</div><div>Size: 42x7 mm</div></div> <div data-bbox="1238 1873 1490 1922"><b>ViewSonic</b></div> | <div data-bbox="1727 1765 1821 1796">Sticker</div> <div data-bbox="1846 1747 2140 1809"><div></div><div><div>Consumo de energia</div><div>100 Wh</div><div>Consumo de energia en</div><div>modo de espera</div><div>3 Wh</div></div><div>S/N: TB0YYWWxxxxx</div></div> |
| <div data-bbox="446 2032 557 2059">UNIT: mm</div>   | <div data-bbox="1097 2030 1346 2061">Date: 06/11/2012</div>           |  |   |