




TJ101 Installation Manual

Image for Setup of TJ101(1/2)



Installation inside PC




TJ101
Module

Coupler:
See page 3

Cable:
See page 3

Image for Setup of TJ101(2/2)



! CAUTION !

- Electrostatic discharge (ESD) can damage electronic components. Before beginning attachment, be sure that you are discharged of static electricity.
- To prevent damage to the TransferJet module, hold the TransferJet module by the edges only. Do not touch the components on the TransferJet module.

○ Available Coupler

- WHA9400-1501E
- WHA9400-1631F
- WHA9400-1626F

○ Available Cable

- U.FL Coaxial Cable (Min. 100mm)



<http://www.smk.co.jp/>
