



# ZONE

WIRELESS  
WRAP EARBUDS

## USER MANUAL



## HOW TO USE

### **Power On/ Power Off:**

- Press and hold the PLAY button for 3 seconds to turn the headset on or off.

### **Charging:**

- While charging. The LED indicator will show a solid red light.
- When completely charged, the LED indicator will show a solid blue light.

### **Low Battery:**

- A low battery alert will play once every 2 minutes.
- If the battery is not charged, the headset will turn off

### **Pairing:**

Before using the headset for the first time, you must pair it with a Bluetooth-enabled device. For pairing the **ZONE - Wireless Wrap Earbuds**

- Press and hold the PLAY button to turn on the headset
- If it's your first time pairing the device it will automatically enter pairing mode.
- If it has been paired but no paired device is in range it will enter pairing mode after 10 seconds. The LED indicator will alternate between blue and red.
- On the device you wish to pair, find the Bluetooth menu and search for or add new devices.
- Select "**ZONE**" from the list of devices
- If asked for a pass/pin code enter 0000 (4 zeros)
- Once the devices are paired, you will hear "connected"

## MULTI-CONNECTION

### **Advanced Multi-point**

The **ZONE Earbuds** are capable of having two devices connected to the headset at the same time. This way you can listen to music from one device, and accept calls from another device without switching your connection.

### **Connection**

- Pair the headset with one of your Bluetooth-enabled devices
- Turn off the headset and the first bluetooth device
- Turn the headset and connect your second device.
- Once the headset is paired and connected, go back and connect the originally paired device to the headset manually. This will now be your secondary handset.

### **Auto-reconnect**

- If the **ZONE Earbuds** are turned off while connected to a device, the device will disconnect. The device will automatically reconnect when the **ZONE Earbuds** are turned back on while in range.
- If there was a secondary device connected it will need to be reconnected manually. Select "**ZONE**" from the list of devices in the Bluetooth menu and pair.

### **Out of range**

- If the paired devices are separated by a range of 33ft (10 meters) or more, the device will disconnect and the **ZONE Earbuds** will vibrate to alert you.
- If the device does not automatically reconnect when it is back within the required range, briefly press the call button on the **ZONE Earbuds** to reconnect manually.
- While in multi-connection mode, if the inactive paired device is disconnected when out of range the **ZONE Earbuds** will not attempt to reconnect.

## **CALLING**

### **Answering a call**

- When there is an incoming call, the headset will ring.
- Briefly press the phone button to answer the incoming call

### **Transferring a call**

- If you make a call from your device, the call will automatically transfer to the headset (*depending on the phone settings*). If the call is not automatically transferred, you can manually transfer the call to or from the headset by pressing and holding the volume up button for 3 seconds on the **ZONE Earbuds** (*handset and headset must be paired*)

This equipment has been tested and found to comply with the limits for A Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against Harmful interference in a residential installation. This equipment , Generates, uses and can radiate radio frequency energy and, if not Installed and used in accordance with the instructions, may cause Harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a Particular installation. If this equipment does cause harmful interference To radio or television reception, which can be determined by turning the Equipment off and on, the user is encouraged to try to correct the

Interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

### ***Last number redial***

- Double click the call button to redial the last number called. The headset will then redial from the device that made the last outgoing call.

### ***Ending a call***

- Briefly press the call button

## **CALLING**

### ***Volume control***

- Briefly press the volume up or volume down button to adjust the headset volume during a call

## **AUDIO STREAMING**

### ***Pause***

- While playing music, briefly press the play/pause/stop button to pause

### ***Play***

- Briefly press the play/pause/stop button to resume

### ***Stop***

- While playing music, press and hold the play/pause/stop button for 1 second to stop all media

### ***Next Song***

- Long press the volume up button to skip the current song

### ***Previous Song***

- Long press the volume up down

## SUMMARY OF BUTTON FUNCTIONS

Function	Current status	Action
Power on	power off	Press and hold the PLAY button 3 seconds to power on
Power off	Power on	Press and hold the PLAY button 3 seconds to power off
Volume up	Talking	Briefly press the "+" button
Volume down	Talking	Briefly press the "-" button
Answering a call	Ringing	Briefly press the call button
Ending a call	Talking	Briefly press the call button
Calling waiting	Talking	Press the call button for 1 second
Last number redial	Idle	Double click the call button
Voice dialing	Idle	Press and hold the PLAY button 1 second can voice dialing
Call reject	Ranging	Long press the call button
Pairing	power off	Press and hold the PLAY button 3 seconds to power on, select 8B071BT from the list of devices
Play	Music on	Briefly press the PLAY/PASUE/STOP button
Pause	Music on	Briefly press the PLAY/PASUE/STOP button
Stop	Music on	Briefly press the PLAY/PASUE/STOP button
Next song	Music on	Long press the "+" button
Previous song	Music on	Long press the "-" button
Operating	Power on	The blue light flickers 4 times
	power off	The blue light flickers 4 times and then turn off
Charging	Pairing mode	The blue and red light alternate flickers
	Headset/ hands-free profile connected	The blue light flickers 2 times every 5 seconds
	Charging	The red light stays on
	charging complete	The blue light stays on
Reset	Power on	Long press the call button and the volume up button at the same time

## SPECIFICATIONS

BT Version: V4.2  
Battery : 120Mah  
Driver unit : 10mm  
Working time : 3-4 hours  
Charging time : 1.5h  
Battery Standby Time : 120h  
Operating distance : 10m

Frequency Range: 2402-2480MHz  
Modulation Type:GFSK,  $\pi/4$ -DQPSK  
Nominal Impedance : 32 ohm  
Output: 0.06W  
Input :0.1W

## FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

© 2018 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

**⚠ WARNING:** Under Prop65, this product may expose you to chemical(s) which are known to the State of California, to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

To activate your product warranty go to our website [www.ihip.com](http://www.ihip.com) & register this product. Limited One Year Warranty. Customer service: 1-800-500-4434



19 Progress St  
Edison, NJ 08820  
[www.iHip.com](http://www.iHip.com)



#iHip



Find us on Facebook.  
Keyword: iHip: Portable  
Entertainment