

User Guide

EBT94

In the Box



Location of Controls

(Front)

1. LED indicator


2. [+]: Quick press - Skip to next track Long press - Increase volume

3. [也]: Quick press - Play/pause Quick press - Answer/end call Double press - Redial last number Long press - Power ON/OFF

4. [-]: Quick press - Skip to previous track Long press - Decrease volume

5. USB port

(Back) 6. Mic



Pairing the Earbuds

- 1. Long press the [也] switch on the side of the earbuds. A voice will indicate that the earbuds are powered ON and in pairing mode and the LED indicator lights will quickly flash BLUE.
- 2. Set your Bluetooth-enabled device to search for Bluetooth devices.
- 3. When your mobile phone (or other Bluetoothenabled device) finds the earbuds, select "EBT94" from the list of found devices.
- 4. After a successful pairing, a voice will indicate that the earbuds are connected and the LED will slowly flash BLUE.

On an iPhone or Android

• Go to SETTINGS > BLUETOOTH (make sure Bluetooth is turned ON)







Using the Earbuds

Powering ON/OFF

- Turn the earbuds ON by long pressing the [也] button. A tone will be heard, indicating that the earbuds are powered ON.
- Turn the earbuds OFF by long pressing the [也] button. A tone will be heard, indicating that the earbuds are powered OFF.

Answering Phone Calls

- To answer a phone call, quick press the [∪]
- To hang up, quick press the [∪] button. Music playback will automatically resume.

Redial Last Number Called

• Double press the [७] button to redial the last number called.

Playing Music

To enjoy music wirelessly on your Wireless Earbuds, make sure that the earbuds are properly paired to your Bluetooth-enabled device. If you are pairing the device for the first time, please consult the "Pairing the Earbuds" section of this user guide.

Playing/Pausing Music

- Quick press the [the pause the music.
- Quick press the [⊕] button again to resume music playback.

Skipping Songs


- Quick press the [] button to go to the previous
- Quick press the [+] button to go to the next

Adjusting the Volume

- · Long press the [] to decrease the volume of music playback
- · Long press the [+] to increase the volume of music playback

Charging the Earbuds

Attach the small end of the micro USB charging cable to the micro USB charging port on the side of the earbuds. Connect the large end to the USB port on your computer or other USB charging device. The LED indicator will turn RED while charging and turn off when fully charged.





Additional Warnings & Precautions

READ CAREFULLY AND KEEP THIS MANUAL

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undersired

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

o Reorient or relocate the receiving antenna.
o Increase the separation between the equipment and receiver.
o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
o Consult the dealer or an experienced radio/TV technician for help.

our customer support line:
Phone: 1-877-768-8481
Monday-Friday 8AM-10PM (EST)

www.southerntelecom.cor Click on "Product Support"

- The device has been evaluated to meet general RF exposure requirement The device can be used in portable exposure condition without restriction.

Questions and Customer Support

Limited Warranty

90 Days Limited Warranty

the package.

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Call the Customer Support number located below, or go
- to our website portal to receive an SRO number.

 Provide proof of the date of purchase within the package
- (dated bill of sale). Prepay all shipping costs to the authorized service center,
- and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within
- Describe the defect or reason you are returning the

our product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier

The shipping address of the authorized service center is:

Southern Telecom, Inc. Attention: Customer Service (2nd Floor)

14-C 53rd Street Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

Phone: 1-877-768-8481 Monday-Friday 8AM-10PM(EST)

Click on "Product Support

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

imitation of Warranty:

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS
- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTIBILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.



Emerson and Emerson and the G-Clef Logo are trademarks and/or registered trademarks of Emerson Radio Corp., used under license. Distributed by: AIT, Inc., Brooklyn, NY 11232 (C) 2016 All Rights Reserved.

