



# HOST PRINTER PCBA




EUT (9493): Main PCBA Component View




EUT (9493): Main PCBA Solder View



EUT (9493): Sub-PCBA1 Component View




EUT (9493): Sub-PCBA1 Solder View



EUT (9493, 9460, 9433): Sub-PCBA 2 Component View




EUT (9493, 9460, 9433): Sub-PCBA 2 Solder View




EUT (9493, 9460, 9433): RF Module PCBA Component View



EUT (9493, 9460, 9433): RF Module PCBA Solder View



EUT (9460, 9433): Keypad PCBA Component View and LCD PCBA Solder View



EUT (9460, 9433): Keypad PCBA Solder View and LCD PCBA Component View