

Radiated Test Setup Placement:

(Worst case: Antenna Polarity--Horizontal: X-axis, Antenna Polarity--Vertical: Y-axis)

