



# Dell Premier Multi Device **Wireless Keyboard and Mouse Combo**


KM7321W

## Quick Start Guide


Wireless Keyboard: KB7221Wt  
Wireless Mouse: MS3121Wt




1




2




3



4




5




2


1



2




3




2


1



2




3




3


1



2




3




3


1




2



3




4



4


1



2




2



3




3



3



<https://www.dell.com/support/drivers>



Dell Peripheral Manager