



**RTL8019 Configuration Mode**

7P (P0)	8P (P1)	Configuration Mode
Low (L)	Low (L)	Normal

**Network Medium Type Select**

PC (P2)	PD (P3)	PE (P4)	Medium Type
Low (L)	Low (L)	Low (L)	10BaseT with LPA test enable

**IRQ Select**

IP (P5)	IQ (P6)	IR (P7)	Interrupt Line
Low (L)	Low (L)	Low (L)	IRQ0

**I/O Base Address Select**

IO (P8)	IO (P9)	IO (P10)	IO (P11)	I/O Base
Low (L)	Low (L)	Low (L)	Low (L)	3200

**RAM size & Base Address Select**

RA (P12)	RA (P13)	RA (P14)	RA (P15)	RA (P16)	RAM Size & Base
Low (L)	Low (L)	Low (L)	Low (L)	Low (L)	0128KB

**NTT AP=MN128-W1AP**

IC6	ETHERNET Controller	
Size	Document Number	Rev
B	66-R70330-00-0	XP
Date	Monday, April 10, 2000	Sheet 2 of 6