

# WLC020 方塊圖

## Transmitter & Receiver

Transmitter frequency( $F_t$ )  
& Receiver frequency( $F_r$ )  
=2412MHz-2484MHz

