



802.11ax-HE20 – Ant 2

Channel 105 (6475MHz) RU26/4

The Reference Level



The Mask Data




Channel 105 (6475MHz) RU52/38

The Reference Level




The Mask Data




Channel 105 (6475MHz) RU106/53

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 113 (6515MHz) RU26/8

The Reference Level



The Mask Data



Channel 113 (6515MHz) RU52/40

The Reference Level



The Mask Data




Channel 113 (6515MHz) RU106/54

The Reference Level



The Mask Data




802.11ax-HE20 – Ant 2

Channel 117 (6535MHz) RU26/0

The Reference Level




The Mask Data




Channel 117 (6535MHz) RU52/37

The Reference Level




The Mask Data




Channel 117 (6535MHz) RU106/53

The Reference Level



The Mask Data




802.11ax-HE20 – Ant 2

Channel 149 (6695MHz) RU26/4

The Reference Level



The Mask Data




Channel 149 (6695MHz) RU52/38

The Reference Level




The Mask Data




Channel 149 (6695MHz) RU106/53

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 181 (6855MHz) RU26/8

The Reference Level




The Mask Data




Channel 181 (6855MHz) RU52/40

The Reference Level




The Mask Data




Channel 181 (6855MHz) RU106/54

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 185 (6875MHz) RU26/8

The Reference Level




The Mask Data




Channel 185 (6875MHz) RU52/40

The Reference Level




The Mask Data




Channel 185 (6875MHz) RU106/54

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 189 (6895MHz) RU26/0

The Reference Level




The Mask Data




Channel 189 (6895MHz) RU52/37

The Reference Level




The Mask Data




Channel 189 (6895MHz) RU106/53

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 209 (6995MHz) RU26/4

The Reference Level



The Mask Data




Channel 209 (6995MHz) RU52/38

The Reference Level




The Mask Data




Channel 209 (6995MHz) RU106/53

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 233 (7115MHz) RU26/8

The Reference Level




The Mask Data




Channel 233 (7115MHz) RU52/40

The Reference Level




The Mask Data




Channel 233 (7115MHz) RU106/54

The Reference Level




The Mask Data




802.11ax-HE40 – Ant 2

Channel 3 (5965MHz) RU242/61

The Reference Level




The Mask Data




Channel 51 (6205MHz) RU242/61

The Reference Level




The Mask Data




802.11ax-HE40 – Ant 2

Channel 91 (6405MHz) RU242/62

The Reference Level




The Mask Data




Channel 99 (6445MHz) RU242/61

The Reference Level




The Mask Data



Channel 107 (6485MHz) RU242/62

The Reference Level



The Mask Data

