



## 802.11ax-HE40 - Ant 0


Channel 123 (6565MHz)




Channel 147 (6685MHz)




Channel 179 (6845MHz)




Channel 187 (6885MHz)




Channel 195 (6925MHz)




Channel 211 (7005MHz)






## 802.11ax-HE80 - Ant 0


## Channel 7 (5985MHz)




## Channel 55 (6225MHz)




## Channel 87 (6385MHz)




## Channel 103 (6465MHz)




## Channel 119 (6545MHz)



## Channel 135 (6625MHz)







802.11ax-HE80 - Ant 0


Channel 199 (6945MHz)

Channel 215 (7025MHz)




802.11ax-HE160 - Ant 0


Channel 15 (6025MHz)




Channel 47 (6185MHz)



Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




## 802.11ax-HE20 Power Spectral Density - Ant 0


26 Tone\_RU0\_CH1 (5955MHz)




26 Tone\_RU8\_CH93 (6415MHz)




26 Tone\_RU0\_CH97 (6435MHz)




26 Tone\_RU8\_CH113 (6515MHz)



26 Tone\_RU0\_CH117 (6535MHz)



26 Tone\_RU8\_CH181 (6855MHz)





26 Tone\_RU0\_CH189 (6895MHz)




26 Tone\_RU8\_CH233 (7115MHz)




## 802.11ax-HE20 Power Spectral Density - Ant 0


52 Tone\_RU74\_CH1 (5955MHz)




52 Tone\_RU77\_CH93 (6415MHz)




52 Tone\_RU74\_CH97 (6435MHz)




52 Tone\_RU77\_CH113 (6515MHz)



52 Tone\_RU74\_CH117 (6535MHz)




52 Tone\_RU77\_CH181 (6855MHz)



52 Tone\_RU74\_CH189 (6895MHz)




52 Tone\_RU77\_CH233 (7115MHz)




802.11ax-HE20 Power Spectral Density - Ant 0


106 Tone\_RU106\_CH1 (5955MHz)




106 Tone\_RU107\_CH93 (6415MHz)




106 Tone\_RU106\_CH97 (6435MHz)




106 Tone\_RU107\_CH113 (6515MHz)



106 Tone\_RU106\_CH117 (6535MHz)



106 Tone\_RU107\_CH181 (6855MHz)



106 Tone\_RU106\_CH189 (6895MHz)



106 Tone\_RU107\_CH233 (7115MHz)

