



802.11a - Ant 1


Channel 113 (6515MHz)




Channel 117 (6535MHz)




Channel 153 (6715MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)




Channel 213 (7015MHz)



Channel 229 (7095MHz)




Channel 233 (7115MHz)




802.11ax-HE20 - Ant 1


Channel 2 (5935MHz)




Channel 1 (5955MHz)




Channel 49 (6195MHz)




Channel 93 (6415MHz)



Channel 97 (6435MHz)




Channel 105 (6475MHz)




802.11ax-HE20 - Ant 1


Channel 113 (6515MHz)




Channel 117 (6535MHz)




Channel 153 (6715MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)






802.11ax-HE20 - Ant 1

Channel 233 (7115MHz)




802.11ax-HE40 - Ant 1


Channel 3 (5965MHz)




Channel 51 (6205MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)



Channel 107 (6485MHz)




Channel 115 (6525MHz)




802.11ax-HE40 - Ant 1


Channel 123 (6565MHz)




Channel 147 (6685MHz)




Channel 179 (6845MHz)




Channel 187 (6885MHz)



Channel 195 (6925MHz)




Channel 211 (7005MHz)




802.11ax-HE40 - Ant 1

Channel 227 (7085MHz)




802.11ax-HE80 - Ant 1


Channel 7 (5985MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)



Channel 119 (6545MHz)




Channel 135 (6625MHz)




802.11ax-HE80 - Ant 1


Channel 151 (6705MHz)




Channel 183 (6865MHz)



Channel 199 (6945MHz)



Channel 215 (7025MHz)




802.11ax-HE160 - Ant 1


Channel 15 (6025MHz)




Channel 47 (6185MHz)



Channel 79 (6345MHz)



Channel 111 (6505MHz)




Channel 143 (6665MHz)




Channel 175 (6825MHz)






802.11ax-HE20 Power Spectral Density - Ant 1


26 Tone_RU0_CH1 (5955MHz)




26 Tone_RU8_CH93 (6415MHz)




26 Tone_RU0_CH97 (6435MHz)




26 Tone_RU8_CH113 (6515MHz)



26 Tone_RU0_CH117 (6535MHz)



26 Tone_RU8_CH181 (6855MHz)



26 Tone_RU0_CH189 (6895MHz)



26 Tone_RU8_CH233 (7115MHz)

