



SIERRA WIRELESS AIRCARD 555 WIRELESS CARD INSTALLATION

FCC RF EXPOSURE INFORMATION

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this device complies with the FCC guidelines and these international standards.

** WARNING **

This device is approved for use only with the **Sierra Wireless AirCard 555** transmitter. This device has been tested and complies with the FCC RF exposure guidelines. Modifications not approved by the manufacturer may result in violation of FCC regulations and may void the Users authority to operate the equipment.

PC Card slots will not operate until a **Sierra Wireless AirCard 555** transmitter is inserted
No other model of transmitter will activate the PC Card slots

Use only the supplied or an approved antenna. See below for detail. Unauthorised antennas, modifications, or attachments could impair call quality, damage the phone, and will result in violation of FCC regulations and **will void the FCC ID.**

When equipped with the **Sierra Wireless AirCard 555**, this product **can only be used in Canada and USA.** This device has not been tested to comply with any other international standards bodies

The FCC ID shown on the CE8640 unit applies only when the **Sierra Wireless AirCard 555** is installed.

For more information about RF exposure, please visit the FCC web site at www.fcc.gov
For more information about the product certification, please contact support@daptech.com

Installation of the Card



A software driver needs to be installed to activate the card.

**** The driver needs to be installed before the card is inserted**

Contact your software integrator or Dap Technologies Technical Support for more information. For more information refer to the CE8640 Technical Guide at <https://www.daptech.com>

You also need an account with a wireless provider.




To install the card:

- Open the Expansion Bay as specified in previous section “Use of PC Card”.
- Slide the AirCard 555 into either of the 2 slots
- Insert the antenna cable into the PC Card connector
- Install the antenna by screwing it on the antenna connector. Do not over-tight



Replacement



Be sure to replace the antenna with the appropriate one.

Dap Technologies Part Number DCCE811