







DA Thumbstick (Teleport, Rotate)*

Menu button

Trigger (Select)

Grab button (Grasp)

Quickly blinking:

Blinking (2 times):

Low battery level

Microphones (2)

Activity light

Menu button

Windows® button

6 Grab button (Grasp)

Quickly blinking:

Blinking (2 times):

Blinking (3 times):

Critical battery level

On: Headset is on.

execute your action.

USB/DisplayPort split cable

ES 1 Thumbstick (Teleport, Rotate)*

Make your gesture and then press to

Mini DisplayPort adapter

Microphones (2)

Activity light

2 Menu button

Windows® button

6 Grab button (Grasp)

Quickly blinking:

Blinking (2 times): Low battery level **Blinking (3 times):**

Critical battery level

On: Headset is on.

Mini DisplayPort adapter

EL1 Thumbstick (Teleport, Rotate)*

* Make your gesture and then press to execute your action.

8 Microphones (2)

Menu button TouchPad*

4 Windows® button

Grab button (Grasp)

Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode

Blinking (2 times): Low battery level

Blinking (3 times):

Critical battery level

On: Headset is on.

USB/DisplayPort split cable

FR① Thumbstick (Teleport, Rotate)*

* Make your gesture and then press to execute your action.

Mini DisplayPort adapter

Microphones (2) Activity light

Menu button

Trigger (Select)

Grab button (Grasp)

Quickly blinking:

Low battery level

Blinking (3 times):

Critical battery level

USB/DisplayPort split cable

* Make your gesture and then press to

Mini DisplayPort adapter

execute your action.

Microphones (2)

On: Headset

Activity light

Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times):

TouchPad* Windows® button

Lights

5 Trigger (Select)

Lights

Activity light

Bluetooth® pairing mode

Slowly blinking: Idle mode

Trigger (Select)

TouchPad*

Lights

Low battery level

Bluetooth® pairing mode

Slowly blinking: Idle mode

Trigger (Select)

TouchPad*

Lights

Blinking (3 times):

On: Headset is on.

USB/DisplayPort split cable

DE Thumbstick (Teleport, Rotate)*

* Make your gesture and then press to execute your action.

Mini DisplayPort adapter

Critical battery level

Bluetooth® pairing mode Slowly blinking: Idle mode

TouchPad*

Lights

- EN① Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad*
- 5 Trigger (Select) 6 Grab button (Grasp) Lights
- Quickly blinking: Bluetooth® pairing mode **Slowly blinking:** Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter
- * Make your gesture and then press to execute your action.
- AR1 Thumbstick (Teleport, Rotate)*
- Menu button
- TouchPad*

- 4 Windows® button
- Trigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Bluetooth® pairing mode
 Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2) Activity light
- On: Headset is on. USB/DisplayPort split cable
- Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- ID1 Thumbstick (Teleport, Rotate)* Menu button
- TouchPad*
- 4 Windows® button
- 5 Trigger (Select) 6 Grab button (Grasp) Lights Quickly blinking:
- Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level 8 Microphones (2)
- Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter
- * Make your gesture and then press to execute your action.
- BG Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad* 4 Windows® button 5 Trigger (Select) 6 Grab button (Grasp) Lights
- Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on.
- USB/DisplayPort split cable
- Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- CS Thumbstick (Teleport, Rotate)* Menu button TouchPad*
- 4 Windows® button Trigger (Select)
- 6 Grab button (Grasp)
- Lights Quickly blinking:
- Bluetooth® pairing mode
 Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2) Activity light
- On: Headset is

USB/DisplayPort split cable

* Make your gesture and then press to

Mini DisplayPort adapter

execute your action.

- Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level 8 Microphones (2) Activity light
 - USB/DisplayPort split cable Mini DisplayPort adapter
 - * Make your gesture and then press to execute your action.
 - KKO Thumbstick (Teleport, Rotate)*
 - TouchPad* 4 Windows® button

3 Trigger (Select)

- 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode
- Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level 8 Microphones (2)
- Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to
- Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*
- Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2) Activity light
- USB/DisplayPort split cable Mini DisplayPort adapter
- * Make your gesture and then press to execute your action. Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*
- 4 Windows® button
- Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times):
- Critical battery level 8 Microphones (2)
- Activity light On: Headset is on.

Blinking (3 times):

- USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- HU Thumbstick (Teleport, Rotate)*
- 2 Menu button
- TouchPad*

- Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times):
- Low battery level
- Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter
- execute your action.

- * Make your gesture and then press to
- Thumbstick (Teleport, Rotate)*
- 2 Menu button 3 TouchPad* 4 Windows® button
- 5 Trigger (Select)
- Lights
- Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2)
- Activity lightOn: Headset is on.
- Mini DisplayPort adapter
- USB/DisplayPort split cable
- USB/DisplayPort split cable * Make your gesture and then press to execute your action.

- SK① Thumbstick (Teleport, Rotate)*
- 2 Menu button
- TouchPad*
- Windows® button Trigger (Select)
- Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Blinking (2 times):
- Slowly blinking: Idle mode Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity lightOn: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- SL1 Thumbstick (Teleport, Rotate)*
- 2 Menu button TouchPad*
- Windows® button Trigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Bluetooth® pairing mode **Slowly blinking:** Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level
- Microphones (2) Activity light On: Headset is on
- USB/DisplayPort split cable Mini DisplayPort adapter Make your gesture and then press to execute your action.
- FI Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad* Windows® button
- Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode
- Blinking (2 times): Low battery level Blinking (3 times): Critical battery level Microphones (2)
- On: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to
- SR 1 Thumbstick (Teleport, Rotate)*

execute your action

Menu button TouchPad* Windows® button Trigger (Select)

Activity light

Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times):

Low battery level

Blinking (3 times):

- Critical battery level 8 Microphones (2)
- Activity lightOn: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter
- * Make your gesture and then press to execute your action.
- SE 1 Thumbstick (Teleport, Rotate)* 2 Menu button TouchPad*
- Windows® button Trigger (Select)
- 6 Grab button (Grasp) Quickly blinking: Bluetooth® pairing mode Slowly blinkina: Idle mode Blinking (2 times): Low battery level

Blinking (3 times):

- Critical battery level 6 Microphones (2) 9 Activity light
- On: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter Make your gesture and then press to
- execute your action
- Thumbstick (Teleport, Rotate)*
- 2 Menu button TouchPad*
- Windows® button Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking:
- Blinking (2 times): Low battery level
- Microphones (2) 9 Activity light
- On: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to

execute your action.

- Windows® button 6 Trigger (Select)
- TR 1 Thumbstick (Teleport, Rotate)* Menu button TouchPad*
 - 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
 - Critical battery level 8 Microphones (2) Activity light On: Headset is on.
 - USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
 - UK 1 Thumbstick (Teleport, Rotate)* Menu button
 - TouchPad*

4 Windows® button 5 Trigger (Select)

- 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode **Slowly blinking:** Idle mode
- Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- JA 1 Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*
- 4 Windows® button Strigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- 8 Microphones (2) Activity light On: Headset is on.

Critical battery level

Mini DisplayPort adapter Make your gesture and then press to execute your action

USB/DisplayPort split cable

- KO 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button TouchPad*
 - Windows® button 5 Trigger (Select) 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times):
- Critical battery level 8 Microphones (2) Activity light On: Headset is on.

Low battery level

Blinking (3 times):

- USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- CN 1 Thumbstick (Teleport, Rotate)*
- Menu button 3 TouchPad* 4 Windows® button
- 6 Trigger (Select) 6 Grab button (Grasp) Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode

Blinking (2 times):

- Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter
- Make your gesture and then press to execute your action
- TW 1 Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad* 4 Windows® button 5 Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode
 Slowly blinking: Idle mode
- Critical battery level 8 Microphones (2)
- Activity light On: Headset is on.
- USB/DisplayPort split cable Mini DisplayPort adapter Make your gesture and then press to execute your action

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Windows is either a registered trademark or trademark of Microsoft Corporation in the United

States and/or other countries The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statement

- HR1 Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*
- Windows® button

8 Microphones (2)

On: Headset is on.

USB/DisplayPort split cable

* Make your gesture and then press to execute your action.

Thumbstick (Teleport, Rotate)*

Mini DisplayPort adapter

Activity light

Menu button

4 Windows® button

6 Grab button (Grasp)

5 Trigger (Select)

TouchPad*

Lights

- 5 Trigger (Select) Quickly blinking: Bluetooth® pairing mode
- 6 Grab button (Grasp) Lights Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- TouchPad* Windows® button 5 Trigger (Select) 6 Grab button (Grasp) Lights Quickly blinking:
- NO 1 Thumbstick (Teleport, Rotate)* 2 Menu button

Bluetooth® pairing mode

Blinking (2 times):

Low battery level

Blinking (3 times):

Critical battery level

USB/DisplayPort split cable

PL 1 Thumbstick (Teleport, Rotate)*

Make your gesture and then press to execute your action.

Mini DisplayPort adapter

8 Microphones (2)

Activity lightOn: Headset is on.

Menu button

Windows® button

6 Grab button (Grasp)

Quickly blinking:

Blinking (2 times):

Low battery level

Blinking (3 times):

Critical battery level

On: Headset is on.

USB/DisplayPort split cable

PT 1 Thumbstick (Teleport, Rotate)*

* Make your gesture and then press to execute your action.

Mini DisplayPort adapter

6 Microphones (2)

Activity light

Menu button

Windows® button

6 Grab button (Grasp)

Quickly blinking:

Blinking (2 times):

Blinking (3 times):

Critical battery level

On: Headset is on.

USB/DisplayPort split cable

8 Microphones (2)

Activity light

Menu button

Windows® button

TouchPad*

Low battery level

Bluetooth® pairing mode

Slowly blinking: Idle mode

5 Trigger (Select)

TouchPad*

Lights

Bluetooth® pairing mode Slowly blinking: Idle mode

Trigger (Select)

TouchPad*

Lights

Slowly blinking: Idle mode

- Mini DisplayPort adapter Make your gesture and then press to execute your action BR 1 Thumbstick (Teleport, Rotate)*
 - 5 Trigger (Select) 6 Grab button (Grasp) Lights Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):

Critical battery level

On: Headset is on.

USB/DisplayPort split cable

Mini DisplayPort adapter

8 Microphones (2) Activity light

- * Make your gesture and then press to execute your action. RO 1 Thumbstick (Teleport, Rotate)*
- Menu button TouchPad* Windows® button Trigger (Select) 6 Grab button (Grasp)
- Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle Blinking (2 times): Low battery level Blinking (3 times):

Critical battery level

6 Microphones (2)

- Activity light On: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter * Make your gesture and then press to execute your action.
- RU 1 Thumbstick (Teleport, Rotate)* 2 Menu button TouchPad* 4 Windows® button 5 Trigger (Select) 6 Grab button (Grasp) Lights
- Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):

Critical battery level

execute your action

8 Microphones (2) Activity light On: Headset is on. USB/DisplayPort split cable Mini DisplayPort adapter

* Make your gesture and then press to

- Bluetooth® pairing mode Slowly blinking: Idle mode
- Blinking (3 times): Critical battery level
- Blinking (2 times): Low battery level Blinking (3 times):

© Copyright 2019 HP Development Company, L.P.

accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: February 2019

On: Headset is on.

- Menu button

- execute your action.
- Windows® button 5 Trigger (Select) 6 Grab button (Grasp)
- On: Headset is on.
- 5 Trigger (Select) 6 Grab button (Grasp)
- 4 Windows® button 5 Trigger (Select) 6 Grab button (Grasp)
- Blinking (3 times): Critical battery level 8 Microphones (2)
- 6 Grab button (Grasp) Quickly blinking: Bluetooth® pairing mode Slowly blinking: Idle mode