

#### 4. Internal Photograph of the Host

Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click



Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click




Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click


WLAN Main Antenna



Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A;Satellite W30Dt-A; Satellite Click; Toshiba Click




Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A;Satellite W30Dt-A; Satellite Click; Toshiba Click

WLAN Aux. & Bluetooth Antenna



Host: Notebook Computer

Brand Name: TOSHIBA

Model Name: Satellite W30t-A;Satellite W30Dt-A; Satellite Click; Toshiba Click

