

wireless is here



AIR BOX

wireless remote for air ride

CONGRATULATIONS

on your purchase of the AIR-BOX TRC 1600, you now have the ultimate control device for your active suspension, the AIR BOX is all about ease of operation and long term reliability.

USING THE TRC 1600

1. WIRING INSTRUCTIONS - please look inside for the basic wire connections.
2. OPERATION OF THE REMOTE CONTROLLER - the joysticks are very easy to use, they only need a light touch in order to function. if you've been using a standard toggle switch box, it's going to take some getting used to at first, the pulses are almost instantaneous, and they have a different feel than older technology, so take some time to get used to the way it is. the joystick position instructions on the next page are pretty self explanatory, just keep in mind that with the battery compartment facing you, positions nine through sixteen apply to the left joystick, while positions one through eight apply to the right stick.
the left pancake button is button #1; the right button #2.
3. PROGRAMMING REMOTE CONTROLLERS INTO THE MASTER MODULE (the brain) - open the programming compartment (on the module) located on the opposite side from the wire harness. locate the small button and push on it until the red L.E.D. in the compartment lights up. while holding the button down push any button or joystick on the remote controller until the L.E.D. blinks and shuts off, and you're done. you can have up to two remote controllers on the system at one time. if you program a third remote, the oldest remote code is bumped out.

AIR-BOX

AIR BOX

INSTRUCTIONS:

RED - POWER

BLACK - NEGATIVE

YELLOW/RED - ACC.

UP

YELLOW - REAR/RIGHT

YELLOW/BLACK - REAR/LEFT

GREEN - FRONT/LEFT

GREEN/BLACK - FRONT/RIGHT

DOWN

GRAY - REAR/LEFT

BLACK/GRAY - REAR/RIGHT

WHITE - FRONT/RIGHT

WHITE/BLACK - FRONT

NOTE: FOR SHOW USE ONLY!

NOTE: IGN WIRE MUST BE CONNECTED FOR PROPER OPERATION OF THE AIR BOX


PROGRAM FEATURES:

hold down (program button) on the brain.
then push (on remote) button 1 or 2.
you can program unlimited remotes.


BUTTON 1: push and the entire system goes down.
BUTTON 2: push and the entire system goes up.
BUTTON 1 & 2 TOGETHER: system will go on valet.
YELLOW & RED: ignition wire be sure to connect.



AIR BOX
AIR BOX



1. LEFT / REAR DOWN
2. LEFT / FRONT DOWN
3. RIGHT / FRONT DOWN
4. RIGHT / REAR DOWN
5. LEFT / FRONT UP
6. RIGHT / FRONT UP
7. RIGHT / REAR UP
8. LEFT / REAR UP



9. LEFT FRONT & LEFT REAR DOWN
10. LEFT FRONT & RIGHT FRONT DOWN
11. RIGHT FRONT & RIGHT REAR DOWN
12. LEFT REAR & RIGHT REAR DOWN
13. LEFT FRONT & RIGHT FRONT UP
14. RIGHT FRONT & RIGHT REAR UP
15. RIGHT REAR & LEFT REAR UP
16. LEFT FRONT & LEFT REAR UP



AIR BOX
AIR BOX



AIR BOX

distributor

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



all designs are to be used as shown, no modifications

CAUTION FOR YOUR SAFETY

1. never operate your AIR BOX or any other active suspension system while your automobile is in motion. this is extremely dangerous to you and everyone else on the road.
2. for your safety, HOOK UP THE IGNITION LOCKOUT WIRE. this makes rule #1 above automatic, and you won't have to worry about the kids saying "what's this, pops(mommy, of course)." not to mention your brother is law^^
3. never operate your system when there are people near your vehicle. (it will move sideways and come off the go and if you hit hard enough, and what about the guy checking out your paint flake when you hop it?)
4. please remember you have up to 100ft. of radio range. if you are out of sight of your ride, or aren't planning on using your system, remember to put your AIR BOX into valet mode. see rule #3 as to why.
5. always have AIR BOX, or any control system installed by a qualified professional.
6. REMEMBER, THE air box IS TO BE USED ON SHOW CARS ONLY!!!
7. for your safety, when your vehicle is in motion AIR BOX will not operate



limited warranty

AIR BOX Inc. is dedicated to quality craftsmanship and are pleased to offer this warranty. we suggest that you read throughly. should you have any questions, please contact your dealer or AIR BOX at one of the telephones listed below.

PRODUCT COVERAGE

this warranty covers AIR BOX product accessories

LENGTH OF WARRANTY

this warranty is in effect for one year from the date of first consumer purchase

WHO IS COVERED

this warranty only covers the original purchaser of the product, who must reside in the UNITED STATES

WHAT IS COVERED

this warranty covers product defects or workmanship (parts and labor) in the product

WHAT IS NOT COVERED

this warranty does not cover the following:

1. damage occurred during shipment of the product to AIR BOX for repair (claims must be presented to the carrier)
2. damage caused by accident, abuse, negligence, misuse, improper or failure to follow instructions contained in the owners manual.
3. damage cause by natural disasters, including without limitation, earthquake, fire, flood, storm, or other acts of nature.
4. any cost or expense related to the removal or reinstallation of the product
5. service performed by an unauthorised person, company or association
6. any product which has the serial number defaced, altered, or removed
7. any product which has been adjusted, altered or modified without the consent of AIR BOX
8. any product not distributed by AIR BOX within the UNITED STATES
9. any product not purchased from an authorized AIR BOX dealer

HOW TO OBTAIN SERVICE

1. you are responsible for delivery of the product to an authorized distributor for payment of any initial shipping charges. AIR BOX will at its option, repair or replace the product with a new reconditioned product without charge. If the repairs are covered by the warranty and if the product was shipped to an authorized distributor, it will pay the return shipment charges
2. you should provide a detailed description of the problem(s) of which the service is required
3. you must supply proof of your purchase of the product
4. you must package the product securely to avoid damage during shipment

HOW WE LIMIT IMPLIED WARRANTIES

any implied warranties including fitness for use and merchantability are limited in duration to the period of the express warranty set fourth above and no person is authorized to assume for AIR BOX any other liability in the connection with the sale of this product

HOW WE EXCLUDE CERTAIN DAMAGES

AIR BOX expressly disclaims liability for incidental and consequential damage caused by the product. the term 'INCIDENTAL DAMAGE' refers to expenses of transporting the product to the AIR BOX service center, loss of the original purchaser's time, loss of use of the product, bus fare, car rental, or other cost relating to the care and custody of the product. the term 'CONSEQUENTIAL DAMAGES' refers to the cost of repairing or replacing other property which is damaged when this product does not work properly. the conditions provided under this warranty are exclusive and in lieu of all others.