


1 Basic interfaces


1.1 DCIN

Connect power adapter to the power outlet




1.2 AV/AUDIO

Use AV cable to connect to the TV analog signal/audio output




1.3 HDMI

One end connects HDMI cable, the other end connect HDMI port of high-definition TV.



1.4 ETHERNET

The Ethernet port "LAN" is shown in the figure below.



2 Preparation for start-up

2.1 Use HDMI cable to connect Media Player and TV or projector

2.2 Use AV cable to connect Media Player and older model TV(Av cable is not included)

2.3 Remote control: Open the back cover of the remote control and put the batteries in; please remove the batteries if the remote control will not be used for a long time and put them in a cool, dry place to preserve the electricity in batteries

2.4 After Media Player is turned on, TV automatically switches the signal source or manual operation may be needed (choose HDMI or AV); (The first-time initialization may take about 12 seconds when the system is loading relevant operational programs)

3 Network connection

3.1 The connection of WI-FI wireless router: Login setting - WIFI connection - find your WIFI SSID - double click SSID-click "Connection" - enter the router's password - click "Connect" .

3.2 Ethernet connection: Ethernet connects to LAN port of Media Player - automatic acquisition.

(Note: if the Internet service provider is China Telecom or China Netcom, IP has been assigned, so the only thing to do is directly clicking "Connect")

4 Application store

4.1 Application store includes: Television, game & tools, life, consulting, social app, local decoding app and other APK.

4.2 All resources are from the Internet.

4.3 Searching: Use the remote control to select letters to search and click on the search results to install.

4.4 Ranking: APK is ranked according to the number of download.

5 Play locally

5.1 External hard drive: plug in portable storage device (USB flash disk, mobile hard disk) to the corresponding port of the device.

5.2 The file manager is used to find local file that you want to play and open to play

6 Description on remote control



	On/Off button
	Mute function
	Screen mouse function
	Return
	Home page
	Volume up
	Volume down

7 Product list


Before you buy this product, please make sure that if the following items are included in the color box. In case of any missing item, please contact your local distributor immediately to protect your rights and interests.

No	item	amount
1	Android Media Player	1
2	Remote control	1
3	Power adpter 5V	1
4	Instructions	1
5	Certificate of inspection	1
6	HDMI Cable	1

Remarks: for the reasons that there are different product models and specifications you buy , a tiny difference maybe existence between the packing accessory part and the items listed in the above table,. once that happens, please make the object as the standard.

8 Troubleshooting

No.	Problem	Possible causes	Handling method
1	No display on the TV after start-up	The power supply is not turned on and the indicator is not on	Connect the power and turn on
2	No display on the TV after start-up, the indicator of Mediaplayer Ethernet twinkles	TV HDMI cable is not properly connected	Ensure proper connection of HDMI and the TV is set to display HDMI signal
3	Only the local functions are displayed after start-up	The Ethernet is not properly connected	Connect Ethernet cable and IP address is configured at network setting interface.
	No account is set up for the wireless network	The Ethernet is not properly connected	The information on the wireless network should be configured
	The front-end video server fails to work	The Ethernet is not properly connected	Please enter the interface (Local) – (Application), use a third-party video player temporarily to play online video
4	The video has no sound when playing	The volume is set to zero	Increase the volume
5	Online video playback is not smooth	The network speed is slow	1) If wireless network is used, please switch to the wired network 2) Lower picture quality and choose HD version or smooth version 3) Switch video sources
6	Online video playback fails	Playback error	1) If the error appears from a specific video source, please retry. 2) If the error appears from all video sources, please restart the player
7	Online video playback fails	The front-end system fails to work	Please do not watch this video until the front-end system is repaired
8	Remote control does not work	The batteries are dead or the batteries are improperly installed	Check or replace the batteries
		There are obstructions between player and remote control	Remove obstructions
		The angle between player and remote control is too large	The angle between them should not greater than 160 degrees



Warning: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

名称：WAWAJI 说明书
尺寸：宽210 X 高285mm
印刷：CMYK (正反面印刷)
材质：80g铜板纸