



1. Photograph of the EUT

EUT: WLAN module (Acer, Gateway, PackardBell / AR5B95)



EUT: WLAN module (Acer, Gateway, PackardBell / AR5B95)



## 2. External Photograph of the Host

Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)




**Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)**



### 3. Internal Photograph of the Host

Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)







**WLAN Main Antenna**

**Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)**



**WLAN Aux. Antenna****Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)**

#### 4. Photograph of Accessory for the Host

Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)





Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)








Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Bluetooth Module

Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)



Bluetooth Module

Host: Notebook Computer (Acer, Gateway, PackardBell / NAV50, NAV60)

