


3. Internal Photograph of the Host

Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)




Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)



WWAN Main Antenna <Tx/Rx>

Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)





Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)

WWAN Main Antenna <Tx/Rx>






Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)

WWAN Aux. Antenna <Rx only>




Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)

WLAN Main Antenna <Tx/Rx>



Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)

WLAN Aux. Antenna <Tx/Rx>




4. Photograph of Accessory for the Host

Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)






Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)





Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)





Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)



Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)




Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)




Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)



Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)




Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)



Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dor m/u; dor mr/u)

Bluetooth Module



Host: Notebook Computer (Acer, Gateway, PackardBell / ZH8, ZH7 / Aspire one, AS1810T, AS1410, AS1810TZ; EC14 series, EC18 series; dot m/u; dor mr/u)

Bluetooth Module

