


1. External Photograph of EUT

Brand Name: Acer / Model Name: A500



Brand Name: Acer / Model Name: A500




Brand Name: Acer / Model Name: A500

Sample 3



Brand Name: Acer / Model Name: A500





2. Photograph of Accessory

Brand Name: Acer / Model Name: A500


List of Accessory:

Specification of Accessory		
Battery 2	Brand Name	SANYO
	Model Name	BAT1010 (GC02001FU00)
USB Cable 2	Brand Name	ICT
	Model Name	DC081001A100
USB Cable 3	Brand Name	MEC
	Model Name	DC081001A100
LCM Main	Brand Name	AUO+Cando W/T-con
	Model Name	AUO B101EW05 V1+Touch (PK37A002610)
LCM 2nd	Brand Name	AUO+Cando W/T-con
	Model Name	AUO B101EW05 V1+Touch (PK37A002620)
eMMC 1	Brand Name	Sandisk 16G
	Model Name	SDIN4C2-16GB (SA00003YE30)
eMMC 2	Brand Name	Sandisk 64GB
	Model Name	SDIN5F1-64G
eMMC 3	Brand Name	Samsung 64GB
	Model Name	KLMCGAFEJA-B001
Camera Main	Brand Name	LITEON
	Model Name	10P1SA505 (PK40000AN10)
Camera 2nd	Brand Name	LITEON
	Model Name	11P2BA501 (PK40000DX00)
LP DDR 2 1	Brand Name	ELPIDA 8Gb 40nm
	Model Name	SA000048Q20
LP DDR 2 2	Brand Name	Hynix 8G 44nm
	Model Name	SA00004MJ00
Docking	Brand Name	Acer
	Model Name	ADT-002

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Acer / Model Name: A500

Battery 2





Brand Name: Acer / Model Name: A500

(型號/型号) **BAT1010** (2ICP5/67/90)
(鋰聚合物電池組/鋰聚合物電池組) Rechargeable Li-polymer Battery Pack
(電壓/电压) Rating: 7.4V (容量/容量) 3260mAh, 24Wh

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions. Risk of Fire and Burns. Do not Open, Crush, Heat Above (manufacturer's specified maximum temperature) or Incinerate. Follow Manufacturer's Instructions. Charging current 1.625A/voltage 8.4V. Max operation temperature is 40°C.

ACHTUNG: Bei Verwendung anderer Batterien besteht Feuer oder Explosionsgefahr. Siehe die Vorsichtsmaßnahmen in der Bedienungsanleitung. Wenn Sie Fragen oder Kommentare bezüglich der Akkubatterie haben, wenden Sie sich bitte an den Computerhersteller.

ATTENTION! A remplacer que par une autre batterie de meme type ou de meme qualite recommandée par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.


危険: バッテリーパックを分解、改造、火中に投入、ショート、あるいは指定された充電方法以外では充電しないでください。守らないと、火災、破裂、発熱の原因となります。
注意事項: 請參閱說明書的安全指示使用電池，如有問題請與電腦供應商聯絡。使用其他電池替換，將可能引起安全問題。
注意事項: 請參閱說明書的安全指示使用電池，如有問題請與電腦供應商聯絡。使用其他電池替換，將可能引起安全問題。



廢電池請回收



TIS 2217-2548
Acer Computer Co., Ltd.



日本エイサー株式会社



B42 KC 2011 04 BT00203002B1421C0BB400

(中國製造/中国制造) MADE IN CHINA

SAY (BJN) CM-3



Brand Name: Acer / Model Name: A500



Brand Name: Acer / Model Name: A500

USB Cable 3



Brand Name: Acer / Model Name: A500




Brand Name: Acer / Model Name: A500



Brand Name: Acer / Model Name: A500



Brand Name: Acer / Model Name: A500

Brand Name: Acer / Model Name: A500



Brand Name: Acer / Model Name: A500

