


# **Exhibit N: Frequency Block Diagram**

**FCC ID: HN2EASYLAN**



† THE HFA3842 MUST BE SUPPLIED WITH A SEPARATE 48MHz CLOCK WHEN USB IS USED.