

*<Model: PTZ-1231W>*



Photo-9 Top view of PTZ-1231W




Photo-10 Bottom view of PTZ-1231W




Photo-11 Bottom cover removed (PTZ-1231W)




Photo-12 Surface of Control board (PTZ-1231W)




Photo-13 Reverse of Control board (PTZ-1231W)




Photo-14 Surface of Sensor board (PTZ-1231W)




Photo-15 Reverse of Top cover (PTZ-1231W)




Photo-16 Surface of Touch Pad (PTZ-1231W)




Photo-17 Surface of Touch Pad (PTZ-1231W)




Photo-18 Surface of Touch Pad (PTZ-1231W)