

## Connectorized Products Model Numbers:

<b>Trade Name</b>	<b>Model Number</b>	<b>Description</b>
Tsunami Multipoint 20MB Subscriber Unit, Ext Ant	40100-252C	Connectorized 20M SU
Tsunami Multipoint 40MB Subscriber Unit, Ext Ant	40100-452C	Connectorized 40M SU
Tsunami Multipoint 60MB Subscriber Unit, Ext Ant	40100-652C	Connectorized 60M SU
Tsunami Multipoint 20MB Base Station Unit, Ext Ant	40400-25C	Connectorized 20M BSU
Tsunami Multipoint 60MB Base Station Unit, Ext Ant	40400-65C	Connectorized 60M BSU
Tsunami QuickBridge 20MB, Master, Ext Ant	40100-28MC	QB 20 Master
Tsunami QuickBridge 60MB, Master, Ext Ant	40100-68MC	QB 60 Master
Tsunami QuickBridge 20MB, Slave, Ext Ant	40100-28SC	QB 20 Slave
Tsunami QuickBridge 60MB, Slave, Ext Ant	40100-68SC	QB 60 Slave
Tsunami QuickBridge II 20, Master, Ext Ant	40100-29MC	QB II 20 Master
Tsunami QuickBridge II 20, Slave, Ext Ant	40100-29SC	QBII 20 Slave
Tsunami QuickBridge II 60, Master, Ext Ant	40100-69MC	QB II 60 Master
Tsunami QuickBridge II 60, Slave, Ext Ant	40100-69SC	QB II 60 Slave
Tsunami QuickBridge II with T1/E1, Master, Ext Ant	40100-49MC	QB II with T1/E1 Master
Tsunami QuickBridge II with T1/E1, Slave, Ext Ant	40100-49SC	QBII with T1/E1 Slave