


# InFocus-FXN-Jtouch65c-ID label

**BEFORE** on-line print  
260mm +/-0.2



**AFTER** on-line print



## MODIFY LOG

VER	DATE	DESCRIPTION	REMARK
20141114	20141114	Frist Release	
20141117	20141117	Change "LIGHTCAST LAN" to "LIGHTCAST LAN & LIGHTCAST USB 2.0"	劉玉寧141114/lawrence 141117 Mail
20141119	20141119	增加無線網卡信息	劉玉寧141119Mail
20141122	20141122	Change "LIGHTCAST LAN" to "LIGHTCAST LAN & LIGHTCAST USB 2.0"	Lawrence 141122 TEL
20141203	20141203	Remove Singapore Korea Taiwan logo	Lawrence&Merry 141203 Mail
20141204	20141204	Remove	Merry 141204 Mail
20141222	20141222	Add output:100-240V,2A,50/60Hz and input Change 2.5A to 4A	Merry and趙康 141204 Mail
20150112	20150112	增加北歐四國的警告和warning警告	Merry and趙康 150112 Mail
20150114	20150114	刪除IC 後面的10字眼	Merry 150114 Mail
20150209	20150209	1.更新FCC ID: I46INF6501C和IC: 8150B-INF6501C 2.CLASS: A. 認證不能取CEC 11669, 需要拿掉 3.以下警告語括號內的字樣改為A. CAN ICES-3 (A)/NMB-3 (A)	趙康 20150209 Mail




尺寸	260*40mm +/-0.2,R=0.5mm	材質	3M7818
顏色	Background color: Black	表面處理	啞油
	Print color/(文字、Mark): White)	加工工藝	輪轉+模切

1.來料為卷裝，印刷文字頭朝內。外卷包裝（見右上圖示）

DESIGN	NAME	DATE	TITLE
DESIGN	Daty Cao	20150209	LBL SAFETY NA Jtouch65c InFocus
APPROVE	Fian Wang	20150209	MODEL NAME: Jtouch65c PART NO.: 50642P650202H06(A)SW

THIRD ANGLE PROJECTION	SCALE	UNITS: mm
	1:1	SHEET 1 OF 1



<b>Bottom panel (left to right)</b>	
Power switch	Press it to the ON position to turn on the monitor, and press it to the OFF position to turn the monitor off.
Power In	Connect the power cord from the monitor to a power outlet.
Power Out	Connect a power cord from an external soundbar or speakers to the monitor.
LAN	For Lightcast use only. Connect to an Ethernet network.
USB Type A 2.0	For Lightcast use only. Connect a wireless mouse, USB thumb drive or other USB device to this USB Type A 2.0 connector.
USB 3.0 Type B	Connect a Type A to Type B USB cable from the monitor to an external computer in order to use the touchscreen gestures on the monitor.
Video	Connect a composite video cable from the monitor to an external device (such as a VCR or DVD player).
HDMI	Connect an HDMI cable from the monitor to an HDMI external device (such as a VCR or DVD player).
HDMI	Connect an HDMI cable from the monitor to an HDMI external device (such as a VCR or DVD player).
HDMI	Connect an HDMI cable from the monitor to an HDMI external device (such as a VCR or DVD player).
HDMI	Connect an HDMI cable from the monitor to an HDMI external device (such as a VCR or DVD player).