

Action Man Radio Controlled Car

I54-12018TX

Requires 4 pieces of 1.5-Volt battery for the Car, and one piece of 9-Volt battery for transmitter.

CAUTION: TO AVOID BATTERY BEAKAGE.

- Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries,
- Always remove weak or dead batteries from the product.

Product and colors may vary.

User cannot modify this product.

MADE IN CHINA