



TSUEN SHING ENTERPRISES LIMITED

Flat 8-10, 8/F., Kar Wah Ind. Bldg., Hei Yip St., Yuen Long, N.T., Hong Kong

Tel: (852) 24740130 Fax: (852) 24731801 Email: tsuenshg@tsuenshing.com.hk

Duplex Headset walkie talkies (toys grade products)

Operation manual

TO OPERATE:

1. A, B unit work in pairs.
2. Remove battery door, insert DC9V battery into battery cabinet, then resume battery door into position.
3. Put on the headset, clip main unit on the belt clip, turn the VOL knob to desired listening level. Place the MIC 1" feet apart from the mouth for talking.
4. Both units can now communicate.
5. As it is duplex function, no need to press PTT button. Both units will transmit & receive simultaneously.
6. Simply talk w/ the MIC & the other party can receive message through headset.

"THE FOLLOWING FACTORS CAN AFFECT THE PERFORMANCE AND OPERATING RANGE OF THE WALKIE TALKIE: COMPUTERS, ACTIVE ELECTRONIC EQUIPMENT, FLUORESCENT LIGHTS AND TALL BUILDINGS."

CAUTION:

1. If your walkie-talkie does not operate properly, try a new set of batteries.
2. After use, always turn off the walkie-talkie & remove batteries.
3. Antenna pointed direction does affect the performance of both TX & RX units. If the antenna pointed direction is moving, it is normal when receiving message turns to be fragmented.
4. Do not touch antenna with your fingers or hand, while you are using walkie-talkie. It will cause weak transmissions.
5. Your walkie-talkie set has been fully adjusted prior to shipment from the factory. Do not touch the internal parts other than to replace battery.
6. To prevent damage, do not expose the walkie-talkie to rain or moisture.

To ensure proper function:

1. Do not mix old and new batteries.
 2. Do not mix alkaline, standard or rechargeable batteries.
 3. Battery installation should be done by an adult.
 4. Non-rechargeable batteries are not to be recharged.
 5. Rechargeable batteries are to be removed from the toy before being charged (if removable).
 6. Rechargeable batteries are only to be changed under adult supervision.
-

7. Only batteries of the same or equivalent type as recommended are to be used.
8. Batteries are to be inserted with the correct polarity, and follow the toy and battery manufacturer's instructions.
9. Exhausted batteries are to be removed from the toy.
10. The supply terminals are not to be short-circuited.

BATTERY INSTALLATION:

Slide the ON/OFF SWITCH to OFF position. Open the battery compartment unit on the back of the unit by pushing in the direction of the arrow and lift. Insert one 9V (6LR61) battery, making sure to correctly connect the positive and negative terminals. Replace the battery compartment door and slide until you feel it lock into place. Each unit requires its own battery.

Technical specifications:

1. Operation frequency: A unit—49.860mhz
B unit—49.405mhz.
2. Power supply: 9V battery 1 pcs.
3. Modulation: AM
4. Communication Distance: 100 feet.
5. Operation current: $\leq 50\text{mA}$
7. Size: 222.8867834mm
8. Net weight: 0.7lbs.

Remark:

Modifications not authorized by the manufacturer may void users authority to operate this device.