

Titan AE Wrist Communicator (49MHz Walkie Talkie)

Operation Manual Draft

The product is provided in pair with following items and control on each unit :

Name of Control on each piece of Walkie Talkie (refer to attached drawing)

1. Antenna
2. Body
3. Talk Button
4. Speaker
5. Wrist Belt
6. Volume Switch (off-low-high position)
7. Battery door

Battery installation

- unscrew the **Battery Door** to open the battery compartment
- install three AAA size batteries (take note of the polarity)
- Close the **Battery Door** and screw it tight

Operation

The product is operated in pair as below with one party talking (transmitting signal) and the other party listening (receiving signal)

Talking (Transmission)

- pull out the **Antenna** until it is 90 degree to the body
- push the **Volume Switch** from **off** position to **low** position
- push the **Talk Button** inward and hold it while talking toward the **Speaker** at a distance of 10cm from the **Speaker**

Listening (Receiving)

- make sure **Antenna** is pull out and **Volume Switch** is push to either **low** or **high** position
- user will hear the transmitting party's voice (make sure the **Talk Button** is not push and hold)

Note :

1. Be careful not to touch the **Antenna** while using the walkie talkie as it will affect signal receiving
2. Adjust the **Volume Switch** to **high** position in case voice is small
3. User can put the walkie talkie on their wrist with the **Wrist Belt**

