## Instructions for CS3BT

## **Three Button Entry Transmitter**




The three button transmitter is used for the remote control of two GTO gate openers or one GTO gate opener and two garage door openers. A GTO Universal Receiver (RB709U-NB) is required for use with non-GTO garage door openers.

You can have as many transmitters as you want for family and guests to open your gate. The DIP switches in all the transmitters for a particular gate opener must be set the same.

#### Cloning/Learning a DIP switch code:

- 1. Press and hold button 1 and button 3 at the same time for about 5 seconds.
- 2. The LED will turn on, then release the buttons.
- 3. Press and release the button that you want to learn a DIP switch transmitter to just ONCE.
- 4. Hold the DIP switch transmitter with the front/top facing the clip side of the Smart Transmitter.
- 5. Press the button on the DIP switch transmitter
- 6. The LED on the Smart Transmitter will blink twice when it has successfully learned the code.


The button you programmed will now transmit the DIP switch code as indicated by the LED being solid on when the button is pressed.



### Creating a DIP switch code:

- 1. Press and hold button 1 and button 3 at the same time for about 5 seconds.
- 2. The LED will turn on, then release the buttons.
- 3. Quickly press 2 times the button you wish to create a DIP switch code for.
- 4. The LED will then blink twice showing successful creation of a DIP switch code.

The button you programmed will now transmit the DIP switch code as indicated by the LED being solid on when the button is pressed.



## Instructions for CS3BT

# **Three Button Entry Transmitter**



The three button transmitter is used for the remote control of two GTO gate openers or one GTO gate opener and two garage door openers. A GTO Universal Receiver (RB709U-NB) is required for use with non-GTO garage door openers.

You can have as many transmitters as you want for family and guests to open your gate. The DIP switches in all the transmitters for a particular gate opener must be set the same.

#### **Deleting a DIP switch code:**

- Press and hold button 1 and button 3 at the same time for about 5 seconds.
- 2. The LED will turn on, then release the buttons.
- 3. Press and hold for 5 seconds.
- 4. The LED will blink twice indicating the DIP switch code was successfully removed.

This button will now transmit the GDO serial number packet as indicated by the LED blinking when the button is pressed.







FCC REGULATION: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  Increase the separation between the equipment and receiver.
  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  Consult the dealer or an experienced radio/TV technician for help.

#### ONE YEAR LIMITED WARRANTY

Your GTO® Accessory is warranted by the manufacturer against defects in followed of purchase, provided the recommended installation procedures have been

GTO\* sells its products through authorized retail and on-line channels to ensure that consumers obtain quality pre-sale and after sale support and service. The ventranty on GTO\* products is NOT VALID if the products have been purchased from an unsufficionally, on-line GTO\* estails retail, put-based in any way. To verify that you are buying from an authorized, on-line GTO\* estails retail www.explor.com, or on-18-00-443-GRO\*.

In the case of product failure due to distriction materials or resultable are enforced by either in the one (1) year warranty period, the censor will be required or replaced (at the immuniscriburation option) at no charge to the customer, influenced frequired production (as the Text (Prior, Loss) and Lindardscere, Finding All Indianesses, Findi

The manufacturer will not be responsible for any charges or damages incurred in the removal of the defective parts for repair, or the reinstallation of these parts after repair. Use of any components that are not GTO<sup>®</sup> specified (e.g. battery or transformed will wid the warranty. The warranty has the correlation will off the manufacturer will be considered with a productify the productify was been to imprope installation or use, use of non-GTO<sup>®</sup> specified or approved components or replacement parts, connection to an improper power source, or if clamps was causastly lighting, electrical power suggest, with the first installating agents.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty is in lieu of all other warranties, either expressed or implied

After the one (1) year warranty period expires, GTO® (or one of its authorized service centers) will perform necessary repairs for a nominal fee. Call GTO® at (800) 543-1236 or (850) 575-4144 for more information.