


Front PVC sheet



Back PVC sheet




KIDdesigns	Rahway, NJ
Project: MD-212.FEv0	Designer: RD
GB Description: BLISTER ON WHITE PVC SHEET 203L x 45W x 267H (mm)	
Version: 5 of 5	Created Date: 04.17.20 Revision Date: 00.00.00
The information contained herein including, but not limited to, the products, renderings, concepts, and designs comprise intellectual property of KIDdesigns, Inc. and shall be kept confidential and shall not be used or disclosed by the recipient without the authority of the KIDdesigns, Inc.	

Label



THE MANDALORIAN
THE CHILD.

LIGHTS & SOUNDS WALKIE TALKIES
ÉMETTEURS-RÉCEPTEURS PORTATIFS
AVEC EFFETS LUMINEUX ET SONORES



Battery Installation

Note: Batteries should always be installed by an adult.

1. Use a Phillips screwdriver to open the battery compartment door located on the back of the unit.
2. Insert 3 "AAA" (R03) batteries into each Walkie Talkie with + and - terminals as indicated in the compartment.
3. Replace the compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten the screw.
4. One or more Walkie Talkies include 3 LR44 button cell batteries for in-store demonstration purposes only. Remove these batteries before use. Keep out of reach of children. Dispose of properly.

Installation des Piles

REMARQUE : Les piles doivent être installées par un adulte uniquement.

1. À l'aide d'un tournevis Phillips, ouvrir la trappe du compartiment des piles situé à l'arrière de l'unité.
2. Insérer 3 piles « AAA » (R03) dans chaque émetteur-récepteur portatif avec les bornes + et - tel qu'indiqué dans le compartiment.
3. Remplacer la trappe du compartiment et serrer le vis à l'aide d'un tournevis Phillips. Ne pas trop serrer le vis.
4. Un ou plusieurs émetteurs-réceptifs portatifs contiennent 3 piles boutons LR44 à des fins de démonstration uniquement en magasin. Retirer ces piles avant utilisation. Garder hors de la portée des enfants. Éliminer correctement.

BANNER

eKids

Distributed by/Distribué par eKids, LLC. • 1299 Main Street, Rahway, NJ 07065.
www.eKids.com • MANUFACTURED IN CHINA/FABRIQUÉ EN CHINE.

CONSUMER INFORMATION: PRODUCT: Lights and Sounds Walkie Talkies. AGE GRADE: Ages 3 and over. WARRANTY: One year limited warranty. Visit www.eKids.com/support for details. Valid only in U.S.A. CONTENTS: 2 Walkie Talkies. REQUIREMENTS: 6 x "AAA" (R03) batteries (not included). • 3 x "LR44" Button Cell batteries are included for in store TRY ME demo mode only. • Batteries included in this box are for demonstration purposes only. • Do not mix old and new batteries, and do not mix alkaline, carbon-zinc, or rechargeable nickel-cadmium batteries. • Insert batteries with correct polarity (+/-) as indicated. • Do not attempt to recharge non-rechargeable batteries. • To prevent battery leakage or damage, remove batteries from product if it will not be used for a month or longer. • Use extreme caution handling leaking batteries (avoid direct contact with eyes and skin). If battery leakage comes in contact with eyes, IMMEDIATELY flush the eyes with gently flowing, lukewarm water for at least 30 minutes. If skin contact occurs, wash skin with clear water for at least 15 minutes. Seek medical attention if any symptoms occur. • Follow applicable laws and local regulations for the disposal and transportation of batteries. • DO NOT DISPOSE OF BATTERIES IN A FIRE. BATTERIES MAY EXPLODE OR LEAK. • Product specifications and colors may vary from photo. • Packaging should be kept as it contains important information.

INFORMATIONS POUR LE CONSOMMATEUR: PRODUIT : Émetteurs-Récepteurs Portatifs avec Effets Lumineux et Sonores. PUBLIC : 3 ans et plus. GARANTIE : Garantie limitée d'un an. Visitez www.eKids.com/support pour plus de détails. Valable uniquement aux États-Unis. CONTENU : 2 émetteurs-récepteurs portatifs. REQUIS : 6 piles « AAA » (R03) (non incluses). • 3 piles de type bouton « LR44 » sont incluses pour une démonstration en magasin uniquement. • Les piles incluses dans cette boîte sont réservées à des fins de démonstration. • Ne pas mélanger des piles neuves avec des piles usagées, et ne pas mélanger des piles alcalines, des piles au carbone-zinc ou des piles rechargeables au nickel-cadmium. • Insérer les piles avec la polarité adéquate (+/-) comme indiqué. • Ne pas essayer de recharger des piles non rechargeables. • Retirer les piles si l'appareil n'est pas utilisé pendant une période d'un mois ou plus afin de les empêcher de couler ou d'être endommagés. • Faire très attention lors de la manipulation de piles qui coulent (éviter tout contact direct avec les yeux et la peau). Si la pile qui présente un écoulement entre en contact avec les yeux, rincer IMMÉDIATEMENT avec de l'eau courante tiède pendant au moins 30 minutes. En cas de contact avec la peau, laver soigneusement avec de l'eau claire pendant au moins 15 minutes. Consulter un médecin en cas de symptômes. • Se conformer aux lois applicables et règles locales pour l'élimination et le transport des piles. • NE PAS JETER DE PILES DANS UN FEU. CELLES-CI POURRAIENT EXPLOSER OU COULER. • Les caractéristiques et la couleur du produit peuvent différer de celles de la photo. • Conserver l'emballage étant donné qu'il contient d'importantes informations.

MD-212.FEv0



DON'T FORGET THE BATTERIES!
N'OUBLIEZ PAS LES PILES!

6 x "AAA" BATTERIES REQUIRED (NOT INCLUDED)
The batteries included in this box are for demonstration purposes only.

6 PILES « AAA » SONT REQUISES (NON INCLUSES)
Les piles incluses dans cette boîte sont réservées à des fins de démonstration.

starwars.com
© & ™ Lucasfilm Ltd.

FCC Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: All controls, adjustments and switches that's instructed in the manual or follow-up instruction provided by the manufacturer that may be operated or adjusted without resulting in a violation of FCC rules.

WARNING: Any adjustment that could result in a violation of FCC rules and it's recommended that could be performed only by or under the immediate supervision and responsibility of a person certified as technically qualified to perform transmitter maintenance and repair duties in this radio service by an organization or committee representative of users of that service.

Effective September 30, 2019, no person shall sell or offer for sale hand-held portable radio equipment capable of operating under FRS and under any other licensed or licensed-by-rule radio services in CFR Title 47 Chapter 1.

Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the IC/FCC equipment authorization for this radio could violate

IC/FCC rules.

Portable Radio Operation and RF Exposure

Antenna Care
Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the radio and may violate FCC/IC regulations.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.