



Instruction Manual Remote-Control Submarine

Battery Installation - Submarine

- Before installation of batteries, you are advised to make sure that the Submarine's Power Switch has been turned to OFF position.
- As indicated in the diagram, slide the stopper forward (located at the submarine's rear) and remove the battery compartment by turning in the clockwise direction.
- Take out the battery box and insert 4 x UM3 (AA) alkaline batteries (not included). Place the batteries in a correct polarity.
- Put the battery box back into the hull as showed in the diagram position.
- Close the battery compartment and fit the hatch and turn anti-clockwise direction. Make sure the hatch firmly and tightly fit as to avoid water leaking into the battery box.

Transmitter

- Open the battery screw with "+" screwdriver.
- Install one piece of 9V (6F22) battery (not included). Place the battery in a correct polarity.
- Close the battery door.

Operation of the Submarine

ADVICES TO THE USER ABOUT OPERATION OF THE SUBMARINE, BEFORE PUTTING IT INTO THE WATER!

- USING TRANSMITTER TO TEST THE SUBMARINE'S SCREWS AND MOVES TO YOUR PREFERRED DIRECTION.
- CHECK THE MAXIMUM CONTROLLABLE DISTANCE BETWEEN THE TRANSMITTER AND THE SUBMARINE. WHEN THE SUBMARINE RECEIVES NO SIGNAL FROM THE TRANSMITTER, IT WILL FLOAT TO THE WATER SURFACE.
- PUT AN APPROPRIATE HORIZONTAL WEIGHT INTO THE SUBMARINE; OTHERWISE, THE SUBMARINE WILL SINK INTO THE WATER.

- Adjust the Left / Right Screws to your preferable angle by hands. The angle will affect the Submarine float on the water surface or quick dive into water.
- Turn on the power by pushing to "ON" position.
- Place the Submarine on the water.
- Using Transmitter to control the Submarine.
- By adjusting the angle of the left / right screws, the submarine can make a tornado dive or rolling dive.

Battery Information

- For better performance and longer operating time, we recommend the use of Alkaline-type batteries.
- Do not mix battery types.
- Do not use rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Do not use mercury oxide batteries.
- Remove exhausted battery to avoid leakage.
- Do not short circuit battery contacts.
- Do not dispose of in fire.
- When the unit's becomes weak, it is the time to replace batteries.
- If the units are not to be used for an extended period of time, please remove the batteries. Old and leaking batteries can cause damage to the unit and may void the warranty.
- Rechargeable batteries are only to be charged under adult supervision.

Care and Maintenance

- Clean your units with cloth. Solvent or detergent should never be used.
- Children should be made aware of the dangers associated with playing near water.
- Ensure your units are turned off before attempting to pick up Submarine.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY UNAUTHORIZED MODIFICATIONS TO THE EQUIPMENT. SUCH MODIFICATIONS WILL VOID THE USER'S GUARANTEE. SPECIFICATIONS AND COLORS OF CONTENTS MAY VARY FROM PHOTO. SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. PLEASE KEEP THIS INFORMATION FOR FUTURE REFERENCE.

© Copyright 2003 Loyal Technology Co., Ltd. All Rights Reserved.

