

## Put in the cards & power on


**1** Insert the SIM tool into the hole next to the tray to pop out the tray. Make sure you use the correct size SIM card and don't cut the SIM card.

**2** Insert the SIM card with the gold contacts down, then gently push the tray into the slot. Add a microSD card for additional storage.\*

**3** Press and hold the Power button, then follow the prompts to get started.

## Use the stylus

- Navigate apps, take notes, edit screenshots, color images, and more.
- To remove the stylus, push the stylus inward to release it, then pull it out.
  - To store the stylus, insert it into the slot, then push it until it locks in place.
  - To set up your stylus, swipe up from the home screen and tap **Settings > Stylus**.



## Help & more

- Get answers, updates, and info:
- Help is here:** From the home screen, swipe up and tap **Settings > Help** to learn how to use your phone and get support.
  - Get more:** Get software, user guides, and more at [www.motorola.com/mymotoLETTER](http://www.motorola.com/mymotoLETTER).
  - Get apps:** Tap **Play Store** to browse and download apps.
- Legal information.** This guide provides important legal, safety, and regulatory information that you should read before using your product. For the complete legal information, from the home screen swipe up and tap **Settings > Q**, then type **Legal information**, or visit [www.motorola.com/device-legal](http://www.motorola.com/device-legal).
- Water repellent.** Your phone is not waterproof. For more about your phone's water-repellent design and care, swipe up and tap **Settings > Help**.
- Battery safety.** To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel.
- If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. Charge your phone using a compatible Motorola charger (may be sold separately). Use of other chargers is not recommended. Don't charge your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). Chargers that do not comply with applicable national standards may be unsafe, with risk of death or injury, and may cause slow charging, product damage, or reduced device performance. To view applicable standards and to learn more, see the "Legal information" section of this guide, or visit [www.motorola.com/device-legal](http://www.motorola.com/device-legal).
- Warning about high volume usage.** To prevent possible hearing damage, do not listen at high volume levels for long periods. When your headset volume reaches the high volume threshold, a warning shows. Tap **OK** to dismiss it, or wait one to five seconds, then press the Volume Up button to dismiss the alert and enable the volume to continue to be adjusted.
- Disposal & recycling.** For help recycling products and packaging responsibly, visit [www.motorola.com/recycling](http://www.motorola.com/recycling).
- Class 1 Laser.** This device is classified as a Class 1 Laser product, which is safe in normal use per IEC60825-1:2007 and IEC60825-1:2014. This device complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notice 50, dated June 24, 2007. Do not attempt to modify or disassemble.
- Extreme heat or cold.** Don't use your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). Don't store/transport your phone in temperatures below -20°C (-4°F) or above 60°C (140°F).
- Legal disclaimers.** Features, services and applications are network dependent and may not be available in all areas; additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of printing. Motorola reserves the right to correct or change any information without notice.
- Arbitration.** Your purchase is governed by a binding arbitration clause. For

more information and how to opt-out, see the legal guide that came with your phone.

**Copyright & trademarks.** MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, Android, Google Play and other related marks and logos are trademarks of Google LLC. microSD Logo is a trademark of SD-3C, LLC. USB Type-C\* and USB-C\* are registered trademarks of USB Implementers Forum. All other product or service names are the property of their respective owners.

© 2021 Motorola Mobility LLC. All rights reserved.  
Product ID: **XXX** (Model XT2211-1, XT2211-2, XT2211DL)  
Manual Number: XXXXXXXX-A

**moto care**

With moto care, extend your warranty coverage up to three years, and take advantage of features like accidental damage protection. Visit [motorola.com/motocare](http://motorola.com/motocare)



\*microSD card is optional, sold separately.





22 Oct 2021