

Meet Your

XT2419-1, XT2419-2, XT2419-3, XT2419V

Put in the card(s) & power on

- 1 Insert the SIM tool into the hole next to the tray to pop out the tray.



Make sure you use the correct size SIM card and don't cut the SIM card.

- 2 Insert the SIM card with the gold contacts down, then gently push the tray into the slot.

Add a microSD card  (optional, sold separately) for additional storage.

eSIM option: Your phone may have an eSIM (embedded SIM card) in addition to the physical SIM card. Contact your service provider for details if you want to activate and use it.

- 3 Press and hold the Power button  to turn on your phone, then follow the prompts to get started.

To turn off your phone, press the Power and Volume Up buttons  +  at the same time.

Use the stylus

Navigate apps, take notes, handwritten text, edit screenshots, perform calculations, and more.

- To remove the stylus, push the stylus inward to release it, then pull it out.
- To store the stylus, insert it into the slot, then push it until it locks in place.
- To set up your stylus, swipe up from the home screen and tap **Settings > Stylus**.

Scan with your **Camera** app for the **User Guide**.
Escanear con la aplicación de la **cámara** para acceder a la **Guía de inicio** y la **Guía del usuario**.

Scan with your **Camera** app for the video.

Wireless charging

Charge your phone using a Qi-certified wireless charger (sold separately).

cause slow charging or product damage. To view applicable standards and to learn more, see the "Legal information" section of this guide, or visit www.motorola.com/device-legal.

Warning about high volume usage. To prevent possible hearing damage, do not listen at high volume levels for long periods. When your headset volume reaches the high volume threshold, a warning shows. Tap **OK** to dismiss it, or wait one to five seconds, then press the Volume Up button to dismiss the alert and enable the volume to continue to be adjusted.

Disposal & recycling. For help recycling products and packaging responsibly, visit www.motorola.com/recycling.

Extreme heat or cold. Don't use your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). Don't store/transport your phone in temperatures below -20°C (-4°F) or above 60°C (140°F).

Legal disclaimers. Features, services and applications are network dependent and may not be available in all areas; additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of printing or release. Motorola reserves the right to correct or change any information without notice.

Arbitration. Your purchase is governed by a binding arbitration clause. For more information and how to opt-out, see the legal guide that came with your phone.

Copyright & trademarks. MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, Android, Google Play and other related marks and logos are trademarks of Google LLC. microSD Logo is a trademark of SD-3C, LLC. USB Type-C* and USB-C* are registered trademarks of USB Implementers Forum. All other product or service names are the property of their respective owners.

© 2024 Motorola Mobility LLC. All rights reserved.
Product ID: Model XT2419-1, XT2419-2, XT2419-3, XT2419V
Manual Number: XXXXXXXXXX-A

 **moto care**

With moto care, extend your warranty coverage up to three years, and take advantage of features like accidental damage protection.
Visit motorola.com/motocare. (U.S. only, except PR.)



Help & more

Get answers, updates, and info:

- **Help is here:** From the home screen, swipe up and tap **Settings > Help** to learn how to use your phone and get support.
- **Get more:** Get software, user guides, and more at www.motorola.com/mymoto.
- **Get apps:** Tap **Play Store** to browse and download apps.
- **Connect with 5G:** 5G service plan and 5G network coverage required; available only in select areas; device not compatible with all 5G networks. Contact your service provider for details.

Caution: Screen protectors may reduce your phone's touchscreen sensitivity. Do not use screen protectors thicker than 0.5 mm.

Legal information. This guide provides important legal, safety, and regulatory information that you should read before using your product. For the complete legal information, from the home screen swipe up and tap **Settings > ?**, then type **Legal information**, or visit www.motorola.com/device-legal.

Water repellent. Your phone is not waterproof. For more about your phone's water-repellent design and care, swipe up and tap **Settings > Help**.
Charging and battery safety. To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel.

If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. For fastest charging speeds, charge your phone using a Motorola 30W (or higher) USB-C Power Delivery charger and a USB-C to USB-C cable (both may be sold separately). Other compatible chargers and cables may be used to charge the device. However, use of such chargers/cables is not recommended and may result in slower charging speeds. Don't charge your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). Chargers that do not comply with applicable national standards may be unsafe, with risk of death or injury, and may

PART NUMBER



[VDR] [LOC] MMM/YY
Printed in [Country]

motorola.com



BC