



M motorola

Let's get started

Before using your phone, please read the legal. safety, and regulatory information provided with your product Headset lack

Flash

- - -

. .

1.1

- -

. .

. .

00

 \odot

Put in the cards & power on

Nano SIM

MOTORC

- Macro

Camera

Sensor

- Google

Assiatant

Button*

L Volume

- Power

Button

ACTED :: MOTON

Speaker

Buttons

- Fingerprint

L 1.0

One SIM model

Two SIM model

()

1 Insert the SIM tool into

the trav.

the tray hole to pop out

Make sure you use the

correct size SIM card

and don't cut the SIM

2 insert the SIM card(s)

with the gold contacts

down, then gently push

Add a microSD card for

the trav into the slot

additional storage *

 $' \sim$

3 Press and hold the

get started.

Power button, then

follow the prompts to

- -

. .

. .

. .

Help & more

Get answers undates and info:

 Help is here: From the home screen, swipe up and tap Settings > Help to learn how to use your phone and get support

- Get more: Get software user guides and more at www.motorola.com/mymotog. Get apps: Tap Play Store to browse and download apps

Legal information. This guide provides important legal, safety, and information that you should read before using your product. For regulatory i the complete legal information, from the home screen swipe up and tap Settings > Q, then type Legal information, or visit

www.motorola.com/device-lega

Water repellent. Your phone is not waterproof. For more about your phone's water-repellent design and care, swipe up and tap Settings > Help Battery safety. To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel

If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. Charge your phone using a compatible Motorola charger. Use of other chargers is not recommended. Don't charge your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). For more, see the "Legal information" section of this guide, or visit www.motorola.com/device-legal

Warning about high volume usage. To prevent possible hearing damage, do not listen at high volume levels for long periods. When your headset volume reaches the high volume threshold, a warning shows. Tap OK to dismiss it, or wait one to five seconds, then press the Volume Up button to dismiss the alert and enable the volume to continue to be adjusted

Disposal & recycling. For help recycling products and packaging responsibly, visit www.motorola.com/recycling. Extreme heat or cold. Don't use your phone in temperatures below -20°C (-4°E) or above 45°C (113°E). Don't store/transport your phone in temperatures below -20°C (-4°F) or above 60°C (140°F

Legal disclaimers. Features, services and applications are network dependent and may not be available in all areas; additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of printing. Motorola reserves the right to correct or change any information without notice.


Arbitration. Your purchase is governed by a binding arbitration clause. For more information and how to opt-out, see the legal guide that came with vour phone.

SAR information (on e-label). To view specific absorption rate (SAR) values for this phone, from the home screen swipe up and tap Settings > Q, then type Regulatory labels, from your phone's dialpad, type *#07#. or visit www.motorola.com/sar.

Copyright & trademarks. MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC, Google, Android, Google Play and other related marks and logos are trademarks of Google LLC, microSD Logo is a trademark of SD-3C LLC. All other product or service names are the property of their respective owners © 2020 Motorola Mobility LLC. All rights reserved.

Product ID: moto a10 (Model XT2127-2) Manual Number: XXXXXXXX-A

NOROTOM :: MOTOROL



motorola.com

A)

* Press: Say a command or ask a question. Note: This feature may not be available in all languages.

USB-C/Charger

Wicio *microSD card is optional, sold separately.