



User Manual

Federal Communications Commission (FCC) Requirements, Part 15

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment.
--

Quick Installation Guide for Wireless Keyboard and Mouse Combo

THIS UNIT COMPLIES WITH PART 15 FCC RULES.

OPERATION IS SUBJECT TO FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

1. Contents of Package

The package contains the following items:

- Wireless Keyboard
- Wireless Optical Mouse or Wireless Mouse
- Receiver with PS/2 connectors
- Two AA Ni-MH Batteries for Wireless Optical Mouse or two AAA Ni-MH Batteries for Wireless Mouse
- Three AA Alkaline Batteries for Keyboard
- Driver Disk or CD-ROM for Keyboard and Mouse
- Quick Installation Guide

2. Install Hardware

2-1. Connect Receiver (See Illustration ①)

(For PC with a PS/2 mouse port and a PS/2 keyboard port)

Please turn off your computer system first.

- (1) Plug the PS/2 mouse connector (green) of the receiver into the PS/2 mouse port of the PC.
- (2) Plug the PS/2 keyboard connector (purple) of the receiver into the PS/2 keyboard port of the PC.

2-2. Select Linkage Channel for Mouse

(See Illustration ②-1, ②-2)

- (1) The two-channel switch is located inside of the battery case. Open the battery cover and select channel 1 or 2.

(If the selected channel will be interfered by other wireless-mouse users nearby, please change the selected channel to the other channel immediately. Please remember to keep the mouse and the keyboard in the same channel.)


2-3. Select Linkage Channel for Wireless Keyboard (See Illustration ③)

- (1) The two-channel switch is located on the back, right-hand side of the keyboard, which is next to the link button. Select the channel as same as the channel of the mouse.


2-4. Link Mouse and Wireless Keyboard with Receiver (See Illustration ②-1, ②-2, ③ ④)

Please turn on the system.

- (1) Press the ID Link Button on the top of the receiver and the red LED light on the top of the receiver will blink slowly at this time.
- (2) Press the ID Link Button on the bottom of the mouse and the red LED light on the top of the receiver will turn to green and blink quickly.
- (3) Press the ID Link Button on the back of the keyboard and the LED light on the top of the



②-1 Wireless Optical Mouse



②-2 Wireless Mouse



- receiver will turn to red color and also blink quickly.
 (4) If the Linkage is complete, the red LED light will stay in light.

3. Install Software



3-1. System Requirements

- (1) Pentium processor or higher.
- (2) Microsoft Windows 95/98/98SE/NT, Workstation or Server Version 4 (with Service Pack 3) or higher, Windows 2000 and Windows ME.

- 3-2. Insert the disk or CD-ROM to install the drivers of the mouse and the keyboard. Double click the setup file "Setup.exe" and then follow the setup instruction.

- 3-3. The keyboard's driver supports the languages of Traditional Chinese, Simplified Chinese, English, French, German, Spanish, Portuguese, Japanese and Italian.

- 3-4. The mouse's driver supports the languages of Traditional Chinese, English, Japanese and Korean, Italian, German, Spanish, French and Dutch.



4. Notice

- (1) Ni-MH batteries are recommended for the mouse and Alkaline batteries for the keyboard.
- (2) The LED indicator on the receiver will remain the light, but will blink while using the mouse, the keyboard or changing the channel.
- (3) The LED indicators of the wireless optical mouse and the wireless keyboard will turn to red light while they are in the status of low battery. Please change the batteries of the mouse or the keyboard immediately.
- (4) The scrolling wheel of the wireless mouse will turn to red light while the mouse is low battery. Please change the batteries of the mouse immediately.
- (5) Press any mouse button or keyboard button to wake up the mouse or the keyboard while the mouse or the keyboard is in the sleeping mode.

19 Easy Buttons of the Multimedia Keyboard Functions

	Calculator		Volume Up		Web Search
	My Computer		Volume Down		Web Refresh
	Media Player		PC Sleep		Web Stop
	Fast Forward		Mute		Web Forward
	Fast Backward		E-mail		Web Backward
	Stop		Web Home		
	Play/Pause		Web Favorites		