

A03502 Tuning Procedure

The transmitter output level is preset by design and is not adjusted or tuned during the manufacturing process.