

2:1

Beschriftung 1 (433MHz)

Laufende Nummer

*sequential number*

MQ-Nummer

*MQ-Number*

HW/SW/Q-Stand

*HW/SW/Q-status*

Audi-Teilenummer

*Audi- Partnumber*

Herstelldatum (JJWWT)

*Manufacturing date (yywwd)*

Modellname


*Modelname*

MQ-PI

*MQ-PI*


Frequenz = 433 MHz

*Frequency = 433 MHz*



2:1

Beschriftung 1 (433MHz)



2:1

Beschriftung 2 (315MHz)

Laufende Nummer

*sequential number*

MQ-Nummer

*MQ-Number*

HW/SW/Q-Stand

*HW/SW/Q-status*

Audi-Teilenummer

*Audi- Partnumber*

Herstelldatum (JJWWT)

*Manufacturing date (yywwd)*

Modellname


*Modelname*

MQ-PI

*MQ-PI*

Frequenz = 315 MHz

*Frequency = 315 MHz*



2:1

Beschriftung 2 (315MHz)

