


1 Photo documentation of the EUT

1.1 External views:

LF antenna position (the right car side is identical to the left) – blue square



LF antenna position – blue square



HF antenna position (near sunroof) – blue line



Front view – LF antenna



Rear view – LF antenna



Side view – LF antenna



Side view – LF antenna



Connector view – LF antenna



Top view – HF antenna



Connector view – HF antenna



Top view – HF antenna



Detail view – HF antenna





