


6. SETUP PHOTOS


6.1. DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

6.1.1. MASTER CONFIGURATION






6.1.2. SLAVE CONFIGURATION




DFS BACK PHOTO



6.1.3. MASTER DEVICE IN SLAVE CONFIGURATION





END OF REPORT