








Channel 04 (2437MHz) – Chain A













Channel 04 (2437MHz) – Chain B








Frequency	
Auto Tune	
Center Freq	7.000000000 GHz
Start Freq	5.000000000 GHz
Stop Freq	9.000000000 GHz
CF Step	400.0000000 MHz
Auto	Man
Freq Offset	0 Hz





Frequency	
Auto Tune	
Center Freq	11.000000000 GHz
Start Freq	9.000000000 GHz
Stop Freq	13.000000000 GHz
CF Step	400.0000000 MHz
Auto	Man
Freq Offset	0 Hz






Frequency
Auto Tune
Center Freq 23.000000000 GHz
Start Freq 21.000000000 GHz
Stop Freq 25.000000000 GHz
CF Step 400.0000000 MHz Auto Man
Freq Offset 0 Hz

Channel 07 (2452MHz) – Chain A





Frequency
Auto Tune
Center Freq 7.000000000 GHz
Start Freq 5.000000000 GHz
Stop Freq 9.000000000 GHz
CF Step 400.000000 MHz
Auto Man
Freq Offset 0 Hz



Frequency
Auto Tune
Center Freq 11.000000000 GHz
Start Freq 9.000000000 GHz
Stop Freq 13.000000000 GHz
CF Step 400.000000 MHz
Auto Man
Freq Offset 0 Hz

