

Page 4 - TuneView Quick Start

Use the remote's next/previous track buttons to navigate through your Party Shuffle list.

Jukebox Mode

TuneView has a 'jukebox' mode. In this mode, you can queue up songs to play in order. To enable Jukebox mode, select SETUP from the TuneView remote's MAIN MENU and select Jukebox. To queue a song to play, select the song as you would normally. To turn off Jukebox mode, return to the SETUP menu and turn Jukebox mode off.

Playing and Selecting Videos

Playing and selecting videos is similar to playing and selecting songs. When you play a video, your video will be displayed on your computer's screen.

Notices

KEYSPAN TuneView (TVU-200C package)		
Description:	Transceiver	Remote
Model / Part Number:	KYRF-TVUSB-A	TVREM-200C (KYRF-RMLN)
FCC:	ID: JFVKYRF-TVUSB-A-1	ID: JFVKYRF-RMLN-1
		Class B, Part 15; 15.247
CE:	EN 300 328, EN 301 489, EN 60950	
Canada:	IC RSS 210 (Class B)	
Australia/New Zealand:	C-Tick	

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Need help with this Keyspan product? Please contact us at:

web: www.keyspan.com/support/

fax: +1 510 222 0323

telephone: +1 510 222 8802



Rev XIS-TVU200CA0.2007.06

Keyspan TuneView Quick Start

This Quick Start guide is intended to guide you through the basic setup and first use of the Keyspan TuneView. More detailed documentation can be found on Keyspan's website (<http://www.keyspan.com/>). *If you are setting up multiple TuneView units, set them up one at a time.*

Step 1 - Install Software:

Important Note for Mac OS X 10.4.10 users:

The version 1.0 Mac software included on the CD is NOT COMPATIBLE with Mac OS X 10.4.10. This issue has been fixed in version 1.0.1. Version 1.0.1 can be downloaded from our website at <http://www.keyspan.com/>

Put the CDROM in your drive and install the Keyspan software:

MAC:

When the CD icon appears on your desktop, double click on its icon to display its contents. Locate the Keyspan Installer icon and double click to start the installation process. Follow the instructions on-screen.

WINDOWS:

Windows will automatically open the Keyspan CD Browser window. Using the on-screen menus, locate the Keyspan Installer selection and click it to start the installation process. Follow the instructions on-screen.

WINDOWS Vista Tech Note:

During and/or after the software installation, Windows may report "Windows can't verify the publisher of this software", click the "Install this driver software anyway" selection.

When the installer completes, it will launch the TuneView application for the first time.

Step 2 - Install and Setup Hardware:

Connect one end of the USB cable to the USB port on the back of the TuneView USB transceiver. Connect the other end of the USB cable to the USB port on your computer.

WINDOWS Tech Note:

During and/or after the hardware installation, the Windows New Hardware Wizard may ask you to install software several times. Select 'Install the software automatically'. You may also get an additional prompt regarding logo testing, click 'Continue'.

Turn over your TuneView Remote and remove the battery cover. Then insert the two AA batteries according to the label inside the battery compartment and replace the battery cover. Your TuneView remote screen will now turn on.

Press any button on your TuneView remote. This will pair your remote to your TuneView transceiver.

Step 3 - iTunes

Wait for your iTunes data to appear on your TuneView remote. This may take a few moments depending on the number of items in your iTunes library.

Page 2 - TuneView Quick Start

About iTunes Snapshots:

The TuneView software takes a 'snapshot' of your iTunes library. This happens the first time you launch iTunes after rebooting. Since your iTunes library can be dynamic (ie changes when you import a CD, buy something from the iTunes store, delete songs, etc), you should use the TuneView software's Get iTunes Snapshot button or the use the TuneView remote's Resync iTunes command (in the Wizard menu) anytime you make a change to your library.

Step 4 - Finishing Up

Once you see your iTunes data on your remote screen, your TuneView is ready for use!

If you do not see your iTunes data on your remote screen, open the TuneView program for diagnostic information. You can also contact Keyspan support for additional assistance.

To open the Keyspan TuneView program

MAC:

Open the program 'TVUSB Admin.app' located in your 'Applications' folder

WINDOWS:

Open the program 'TuneViewHelper.exe' by clicking the Keyspan icon in the system tray (usually located to the left of the time). If you do not see the Keyspan icon, launch the TuneViewHelper program (located in START menu > (All) Programs > Keyspan TuneView > TuneViewHelper

Using TuneView

Within 75 feet of the dock you will typically find that the RF signal between the dock and the remote is strong (even when the signal is passing through 1-3 residential walls). In this area it will not matter which direction you are facing when using the TuneView remote. Beyond 75 feet, if the signal is passing through 1 or more walls, you may find that you need to point the TuneView remote in the general direction of the TuneView dock in order to obtain good performance.

* Range of 150 feet or more is obtained in open space.

TuneView Buttons

The following describes the buttons on the TuneView Remote:



Page 3 - TuneView Quick Start

You will use these buttons to navigate the TuneView interface.

Up / Down Arrows

Use to scroll up/down menus

Select

Use to select a choice

Play/Pause

Use to play/pause current selection

Menu

Use to return to previous menu

Volume Up / Down

Use to change volume

Next Track [Fast Forward]

Press once to go to next track/chapter

Previous Track [Rewind]

Press and Hold to fast forward

Wizard button

Press once to go to previous track/chapter

Press and Hold to rewind

Wizard button

The Wizard button will display a dynamic/contextual menu based on what you are currently doing. While browsing songs, the Wizard menu will let you jump to the beginning, middle, or end of a list. The Wizard button can also be used as a shortcut to access Mute and to show the current playing song's details (Song Display).

Controlling iTunes

Controlling iTunes is similar to controlling an iPod. The TuneView remote displays your iTunes content in a method that is similar to an iPod. Your starting point is the TuneView main menu.

Scroll up and down the list using the up and down arrow buttons on the remote and select menus using the select button on the remote. You can select a song to start playing it.

Note:

As you select and play your iTunes content, you will see a 'TuneView' playlist added to iTunes with content being added and removed from this playlist. This is normal and is being controlled by the TuneView helper app.

Controlling Radio via iTunes

If you want to select and listen to iTunes radio stations via the TuneView remote, do the following...

In iTunes, navigate to 'Radio'

Select your radio station and start listening to it

Next, drag that radio station name into the iTunes 'Library'

You will now see that station added to your library

It is important to play the radio station once as iTunes will not add the station until you have played the station once. Repeat this process for every radio station you want to control. When you have finished, switch the to the TuneView helper app and click click 'Get iTunes Snapshot'

On the remote, go to the MAIN MENU, go to RADIO - you will see all of radio stations you added to your library. Select the station you want to play.

Party Shuffle

TuneView can control iTunes Party Shuffle feature but you cannot see the contents of that playlist.