



Photographs of EUT



Note: This module will be installed on PCB board and no any metal or PCB cover environment which is similar as the test setup host situation.