
# WISER GUIDE




WELCOME	
In The Box	2
Product Overview	3
Fit	4
Charging	5
Earbuds	5
Case	6
Pairing	7
DETAILED INSTRUCTIONS	
Controls - On/Off	8
Controls - Music & Calls	9
The Jaybird App	10
Smartwatches	13
Connection Tips	14
Troubleshooting	15
Specifications	16
Warranty, Warnings & Safety	17
Care & Maintenance	18

# IN THE BOX



Silicone Eargels (Size 1 / 2 / 3)

## **PRODUCT OVERVIEW**



#### FIT

For an assisted fit set up, please download the Jaybird App or visit www.jaybirdsport.com/support/vista


Your Vista earbuds are fitted with size 2 (medium) eargels out of the box. They are marked 'L' and 'R' for the left and right ear.

Place the earbuds firmly within your ears as shown in the illustration.

If your earbuds are not comfortable, feel loose, or too tight try alternative sized eargels (size1 or size 3).

Be patient, it may take some time to get the perfect fit.

It is quite common to use different sized eargels in each ear.




#### **CHARGING - EARBUDS**

Jaybird Vista offers you 6 hours of playback when fully charged. The charging case gives you two additional recharge cycles or 12 hours additional playback.

Your earbuds will start charging as soon as you place them into the charging case and close the lid. The charging case LED will indicate the charging status:

LED is pulsing white = Charging
LED is solid white = Fully charged

A 5 minute charge gives you up to 1 hour of playback. A full charge of the earbuds can take up to 2 hours if charging them from a discharged state.



#### **CHARGING - CASE**

It takes about 2 hours from a fully discharged state to charge your case.


With the case closed, connect the USB-C charging cable to the front of the charging case. The case LED will indicate the charging status:

LED is pulsing white = Charging
LED is solid white = Fully charged

When the charging case runs low on battery the LED will start blinking red on opening or closing the lid.


Double tap the charging case:

LED is solid red = charging case battery is low
LED is blinking red = charging case battery is very low
LED is pulsing white = earbuds are charging
LED is solid white = earbuds are fully charged



#### **PAIRING**

To pair to a Bluetooth audio device follow the steps below



**CONTROLS - ON/OFF** 

#### **AUTO POWER ON/OFF**

**Turn OFF** - Placing your earbuds into the charging case will automatically turn them off.


**Turn ON** - Removing your earbuds from the charging case will automatically turn them on.

When your earbuds are out of the charging case and are not being used they automatically power off after about 15 minutes.


#### MANUAL POWER ON/OFF

**Turn OFF** – **Long press** on either the left or right button will turn off both earbuds.


**Turn ON** – A **single press** or **long press** will turn on only that particular earbud. Repeat the same procedure on the other earbud to turn on the earbud.



**CONTROLS - MUSIC & CALLS** 



<sup>\*</sup>You can customize a single or double press functions within the Jaybird App



#### THE JAYBIRD APP


The Jaybird App lets you do the following:

- Customize the sound profile of your Vista earbuds.
- Change the language for your earbuds' voice prompts.
- Set up the 'Find Your Buds' feature to track the location of your earbuds.
- Use the 'Find Your Fit' feature to find the right fit for your earbuds.
- Update your earbuds when new features and improvements are available.







Your new sound settings are saved on your earbuds, so you can take your custom sound with you no matter where you go with any device you use.



THE JAYBIRD APP




THE JAYBIRD APP



#### **SMARTWATCHES**

With the right smartwatch you can leave your phone at home. Just sync music to your smartwatch and pair Vista to your smartwatch. Use your smartwatch user manual for instructions on how to pair a Bluetooth device.



#### **CONNECTION TIPS**

Both right & left earbuds can connect to your audio device. The earbuds will automatically switch to get the best connection to the audio device.

For best Bluetooth performance, try to reduce the distance between your earbuds and your audio device. Try to have your audio device in an arm band, or in a belt pocket.


IDEAL DEVICE LOCATIONS

#### **TROUBLESHOOTING**

**Soft reset:** If your earbuds are not responding, place your Vista in the charging case, close the lid and plug the case into charge. This will turn your earbuds off and perform a soft reset.

**Factory reset:** If that does not resolve your problem we recommend resetting your earbuds to their original factory settings. Before starting this process please **FORGET** or **REMOVE** your Vista device from the Bluetooth menu on all your connected audio devices.

- Place both earbuds into the charging case and close the lid.
- Open the charging case and press & hold the case button until the case LED starts blinking white.
- While the charging case LED is blinking white, press the button on the case twice.



The LED will blink
3 times pink. Now close the case.

Your earbuds are reset and ready to pair. Go to your audio device Bluetooth menu and select "Jaybird Vista" to pair again.

## **SPECIFICATIONS**

Bluetooth Version	5.0
Codec	SBC
Profile	Handsfree, A2DP, AVCRP, SPP
Effective Range	10 meters (30 feet)
Play Time	6 Hrs*
Power	Bluetooth headset: 5.0V 🚃 , 1A
Charging Time	2 Hrs
Quick Charge	5 Min = 1 Hr play time
Dimensions	22 x 24 x 18 mm earbud size / 74 x 36.5 x 24 mm case size
Weight	Approx 4.8 g (without eargels)

<sup>\*</sup>Playtime and standby time may vary due to usage conditions. Adding additional bass to your sound profile through the Jaybird app will reduce play time.

# **WARRANTY, WARNINGS & SAFETY**

Full warranty, care & maintenance details at: jaybirdsport.com/warranty +1.866.244.3399

**WARNING:** Due to the isolating characteristics of these earbuds do not use while driving, riding a bike or where vehicular traffic is present, or in any other activity where failure to hear surrounding sounds could be dangerous. Use of these earbuds at excessive volumes may cause permanent hearing damage. Always turn the volume down before use. Take caution in regards to inserting objects into ear canal, use at own risk. Do not wear the device while it is connected to a power source driven from main 110V or 220V lines.

Copyright 2016 Jaybird, LLC. All rights reserved. Jaybird, and the Jaybird logo are trademarks of Jaybird, LLC. Bluetooth is a trademark owned by Bluetooth SIG, Inc. USA, and licensed to Jaybird, LLC. iPhone, iPad and iPod are trademarks of Apple, Inc., registered in the US and other countries and App Store is a service mark of Apple Inc. All other trademarks are the property of their respective owners. Android is a trademark of Google Inc. in the United States and other countries.

#### **WATERPROOF**

Your Jaybird Vista earbuds feature an IPX7 waterproof rating. Vista earbuds are designed to handle rain, mud and outdoor adventures.

Jaybird earbuds are not designed for swimming, showering or exposure to pool or ocean water. In case of exposure to salted or chlorinated water, rinse the earbuds gently with fresh water and air dry before use. The charging case is not water resistant, so please ensure your earbuds are completely dry before charging.

#### **EARGEL CLEANING**

Keeping your Jaybird earbuds eargels clean is essential for safe, hygienic use.

**IMPORTANT:** DO NOT attempt to clean the eartips without first removing them from the earbuds.

- 1. Firmly grip the eargel with one hand and the earbud with the other. Carefully remove the eargel from the earbud.
- 2. Use warm water and mild soap on a damp cloth to remove dirt and earwax from the eargel. Do NOT use harsh cleaning agents.
- 3. Rinse and completely dry your eargel before placing them back on your earbuds.
- 4. Carefully push the eargel back onto the earbuds.

#### LISTEN RESPONSIBLY

Avoid excessive volume levels and prolonged periods of listening. Prolonged listening at excessive volume levels may cause permanent hearing disability.

Do not use around road traffic.

#### **CARE AND MAINTENANCE**

Clean eargels regularly of dirt and wax buildup. To clean, remove eargels from earbuds, then gently wipe away dust and oil with a dry cloth, and/or use warm water and mild soap to remove buildup. Rinse and completely dry before reattaching.

Before charging, ensure earbuds are completely dry of sweat and water.

Video instructions at jaybirdsport.com

