


MX VERTICAL

Setup Guide | Setup Guide

Setup Guide | Setup Guide




logitech®

LETS GET STARTED

You can connect your MX Vertical both wirelessly or through the USB charging cable. Follow the steps below to connect.


Connect with the cable

- Plug the USB cable into your MX Vertical to use it corded.
- Press the Easy-Switch button to select the channel you want to pair to.



Connect Wirelessly


- Press the Easy-Switch button to select the channel you want to pair to. Press & hold the Easy-Switch button for 3 seconds to make it discoverable.



- You can connect MX Vertical via Logitech Unifying USB receiver or *Bluetooth®*.



- Download Logitech Options to get the most out of your MX Vertical.



logitech.com/Options

Learn more about MX Vertical, the ergonomic design, and the advanced features online.



MXVertical.logi.com

www.logitech.com

©2018 Logitech. Logitech, Logi and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners.

©2018 Logitech. Logitech, Logi and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners.