

Wireless All-in-One Keyboard TK820

Setup Guide







Lernen Sie Ihre tur Windows 8

Settings


Settinas

Function Keys




🗘 F5


Switch applications Switch applications Search Search Share Share Devices Devices Devices



Gestures

Gesten





Left-click

Tap with one finger or press the lower left side of the trackpad.

Tap with one finger or press the lower left side of the trackpad.

Right-click


Tap with two fingers or press the lower right side of the trackpad.

Tap with two fingers or press the lower right side of the trackpad.

- + left click disables tap and edge gestures
- + left click disables tap and edge gestures

Edge Gestures (Windows 8)

Edge-Gesten (Windows 8)



Swipe from trackpad edge

Swipe from trackpad edge




Install Logitech software that adds support for customization, extra gestures, and smoother operation

Software Installation

Install Logitech software that adds support for customization, extra gestures, and smoother operation

www.logitech.com/download/tk820



Unifying Unifying

Logitech® Unifying technology connects up to six compatible Logitech mice and keyboards to the same receiver, using only one USB port for multiple devices. To learn more, visit the Unifying product page.

Logitech® Unifying technology connects up to six compatible Logitech mice and keyboards to the same receiver, using only one USB port for multiple devices. To learn more, visit the Unifying product page.

Visit the Product Page

Besuchen sie die Produktsiet

While you're online, visit the Wireless Touch Keyboard Product Page, your destination for worldclass support. In addition to software, you'll find tutorials, troubleshooting tips, and live forums.

While you're online, visit the Wireless Touch Keyboard Product Page, your destination for worldclass support. In addition to software, you'll find tutorials, troubleshooting tips, and live forums.

Troubleshooting Felherbehebung

Touch Keyboard not working?

- Restart the keyboard by turning it off and then back on.
- Move the Unifying receiver to another USB port or plug the receiver directly into the computer instead of a USB hub.
- Check the battery orientation.
- If the status light next to On/Off switch blinks red, replace batteries.
- Using USB 3.0 on your computer? For more information on solving problems with USB 3.0, visit www.logitech.com/support/unifying.

Problem with gestures?

• Avoid resting unused fingers or your palm on the touch surface.

Touch Keyboard not working?

- Restart the keyboard by turning it off and then back on.
- Move the Unifying receiver to another USB port or plug the receiver directly into the computer instead of a USB hub.
- Check the battery orientation.
- If the status light next to On/Off switch blinks red, replace batteries.
- Using USB 3,0 on your computer? For more information on solving problems with USB 3.0, visit www.logitech.com/support/unifying.

Problem with gestures?

• Avoid resting unused fingers or your palm on the touch surface.



www.logitech.com/support/unifying



www.logitech.com

© 2013 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Apple, Mac, and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-00xxxxxxxx

Support

www.logitech.com/support/tk820



Country 1 +x xxx-xxx-xxxx Country 2 +x xxx-xxxx

