

1



2

OPTIMIZA TU TECLADO EN
LOGITECH.COM/K600SETUP
OTIMIZE SEU TECLADO EM
LOGITECH.COM/K600SETUP
OPTIMIZE YOUR KEYBOARD AT
LOGITECH.COM/K600SETUP



3



support.logitech.com/k600tv

Samsung TV (fn) + (4) 3 Sec. | LG TV (fn) + (5) 3 Sec. | Sony BRAVIA & Philips Android TV (fn) + (o) 3 Sec.

2

OPTIMIZA TU TECLADO EN
LOGITECH.COM/K600SETUP
OTIMIZE SEU TECLADO EM
LOGITECH.COM/K600SETUP
OPTIMIZE YOUR KEYBOARD AT
LOGITECH.COM/K600SETUP



3



4



Windows® | Mac
Descarga Logitech Options
en logitech.com/options
Faça download do Logitech Options
em logitech.com/options
Download Logitech Options at
logitech.com/options

Windows® (fn) + (7) 3 Sec. | macOS (fn) + (8) 3 Sec. | iOS (fn) + (9) 3 Sec. | Chrome OS™ (fn) + (o) 3 Sec.